

GARRETT - MELETT Cross Reference

To quickly find a part, use the ctrl+F option. If the part you require is not found, please contact Melett direct with you enquiry.

Melett Ltd

Tel: +44 (0)1924 488686

Fax: +44 (0)1924 459200

Email: sales@melett.com

Melett 2002. All manufacturers names, numbers, symbols and descriptions used herein are for reference purposes only and do not imply that any part listed is the product of these manufacturers.

Garrett Part No.	MELETT PART No	DESCRIPTION
	1100040162	Piston Ring T3 /T04B (Performance step ring) Replacement for 1100040160
	1100025162	Piston Ring T2 / T25 (Performance step ring) Replacement for 1100025160
	1100040752	Repair Kit 360Deg T/Brg T3/T4 Carbon Seal
	1100180135	Bearing T12/T18 OD+.015"/ID Std
	1100025751	Rep Kit 360 Deg T/Brg (Dy T2/25)
	1100040751	Repair Kit 360Deg T/Brg T3/4Dyn
102026-0000	1100020100	Bearing Std. (Short T2/T25)
102034	1100025160	Piston Ring T2 / T25 Turbine end
102034-0000	1100025160	Piston Ring T2 / T25 Turbine end
102101	1100020127	Bearing T2 short Std OD / -0.010" ID
102101	1100020127	Bearing T2 short Std OD / -0.010" ID
102103	1100020114	Bearing T2 Narrow OD +.005"/ ID Std
102103-0000	1100020114	Bearing T2 Narrow OD +.005"/ ID Std
102104	1100020110	Bearing T2 Narrow OD +.005"/ -.005" ID
102104-0000	1100020110	Bearing T2 (Short) OD+.005"/ID-.005
102104	1100020110	Bearing T2 Narrow OD +.005"/ -.005" ID
102107	1100020124	Bearing T2 Narrow OD +.010"/ ID Std
102107-0000	1100020124	Bearing T2 Narrow OD +.010"/ ID Std
102108	1100020131	Bearing T2 Narrow OD +.010"/ ID -.005"
102108-0000	1100020131	Bearing T2 Narrow OD +.010"/ ID -.005"
102109	1100020120	Bearing T2 Narrow OD +.010"/ ID -.010"
102109-0000	1100020120	Bearing T2 Narrow OD +.010"/ ID -.010"
102200	1100025117	Bearing T25 (Long) (OD Std / ID -.005")
102200-0000	1100025117	Bearing T25 (Long) (OD Std / ID -.005")
102203	1100025114	Bearing T25 (Long) (OD +.005"/ ID Std)
102203-0000	1100025114	Bearing T25 (Long) (OD +.005"/ ID Std)
102204	1100025110	Bearing T25 (Long) (OD +.005"/ ID -.005")
102204-0000	1100025110	Bearing T25 (Long) (OD +.005"/ ID -.005")
102207	1100025124	Bearing T25 (Long) (OD +.010" / ID Std)
102207-0000	1100025124	Bearing T25 (Long) (OD +.010" / ID Std)
102209	1100025120	Bearing T25 (Long) (OD +.010" / ID -.010")
102209-0000	1100025120	Bearing T25 (Long) (OD +.010" / ID -.010")
102226	1100025100	Bearing Std. (Long T2/T25)
102226-0000	1100025100	Bearing Std. (Long T2/T25)
103015-0000	1100030400	Comp. Wheel (T3) Trim 60 ss 409096-0006
103016-0000	1100030401	Comp. Wheel (T3) TA0301
103017-0000	1100030403	Comp Wheel T3 TC0301 ss 409096-0004
103217-0000	1100030402	Comp. Wheel (T3)
104026-0000	1100040100	Bearing (T3/TO4B) Standard
104030-0000	1100040140	Snap Ring (thin)
104033-0000	1100040170	Piston Ring T04B C/E
104034-0000	1100040160	Piston Ring T04B(Step.Turb)
104035-0000	1100040200	Thrust Collar (Dynamic T04B) SSB 1100040203
104042-0000	1100040350	Shaft Nut (T04B T3 RHT)Nyloc
104052-0000	1100040320	THRUST BEARING (T04B 2 Hole)
104061-0000	1100040480	CLAMP PLATE TURB

104064-0000	1100040560	BOLT
104065-0000	1100040500	Clamp Plate (TO4B Comp.)
104066-0000	1100040540	Lock Plate (TO4B Comp.)
104072-0000	1100040520	Lock Plate (TO4B Turb.)
104100-0000	1100040117	Bearing Std OD/ .005" ID
104101-0000	1100040127	Bearing T3/T04B OD std/ ID -.010"
104103	1100040114	Bearing OD +.005"/Std ID
104103-0000	1100040114	Bearing OD +.005"/Std ID
104104-0000	1100040110	Bearing Kit +.005"OD/-.005"ID (2 Bearings per kit)
104105	1100040130	Bearing T3/T04B +.005"OD/-.010"ID
104105-0000	1100040130	Bearing T3/T04B +.005"OD/-.010"ID
104107-0000	1100040124	Bearing TO4B OD +.010"/Std ID
104109-0000	1100040120	Bearing +.010" OD / -.010" ID
104112-0000	1100025752	Rep Kit 360 Deg T/Brg (Ca T2/25)
104220-0000	1100040400	Comp.Wheel (TO4B)
104244-0000	1100040360	Seal Plate T04B Dynamic
104327-0000	1100040202	Thrust Collar (TA31 Carb Seal)
104390-0000	1100030270	Carbon Seal T3/T04B
104533-0000	1100040181	Piston Ring T04B C/E +.010" Pink
104534-0000	1100040180	Piston Ring T04B T/end
104542-0000	1100040350	Shaft Nut (TO4B T3 RHT)
104642-0000	1100040350	Shaft Nut (TO4B T3 RHT)SpyLock
104661-0000	1100040480	CLAMP PLATE TURB
104834-0000	1100040183	Piston Ring O/S .710" x .082" T3-T04B
104934-0000	1100040182	Piston Ring T3-TO4B .720"-.082"
105026-0000	1350130100	Bearing (Std.) KTR130
105033-0000	1350130160	Piston Ring (Comp) KTR130 same as 1350130170
105034-0000	1350130160	Piston Ring (Comp) KTR130 same as 1350130170
105035-0000	1350130200	Flinger Sleeve KTR130 (single ring)
105044-0000	1350130300	Insert Plate KTR130 Flat Back
105060-0000	1350130150	O Ring (KTR130 Insert Plate)
105069	1350130240	Thrust Collar KTR130
105069-0000	1350130240	Thrust Collar KTR130
105101-0000	1350130127	Bearing KTR130 Std Bore/-.010" ID
105107-0000	1350130124	Bearing KTR130 +0.010" OD/Std Bore
105109-0000	1350130120	Bearing KTR130 +0.010" OD/-0.010"ID
105135-0000	1350110200	Thrust Collar KTR110
105169-0000	1350110240	Thrust Ring/Spacer KTR110
105252-0000	1350130320	Thrust Bearing KTR130
106060-0000	1100040150	O Ring (B/Hsg TO4B)
112001-0000	1100120700	Core Assy T1210
112002-0000	1100120701	Core Assy T1224
112003-0000	1100120702	Core Assy T1227
112004-0000	1100120750	Service kit (T12) Smooth Bore T1204 - T1210
112005-0000	1100120751	Service kit T12 (major) Smooth Bore
112010-0000	1100120435	Shaft & Wheel T12
112011-0000	1100120436	Shaft & Wheel T12
112013-0000	1100120703	Core Assy T1237
112014-0000	1100120704	Core Assy T1238
112015-0000	1100120400	Comp. Wheel TE06 / T1210
112016-0000	1100120401	Comp. Wheel T1224
112017-0000	1100120402	Comp. Wheel TE06 / T1227
112018-0000	1100120403	Comp. Wheel T1233
112019-0000	1100120404	Comp. Wheel T1237
112020-0000	1100120405	Comp. Wheel T1238
112023-0000	1100120450	Bearing Housing T12
112025-0000	1100120455	Bearing Housing T12
112026-0000	1100120705	Core Assy T1226
112031-0000	1100120706	Core Assy T1231
112033-0000	1100120160	Piston Ring Smooth Bore T12
112034-0000	1100120160	Piston Ring T12 Smooth bore
112035-0000	1100120221	Spacer Sleeve (T12) ssb 1100060200
112036-0000	1100120220	Thrust Spacer (T12) ssb 1100060200
112038-0000	1100180201	Thrust collar TE06 / T12 Use with 1100120221
112039-0000	1100120200	Thrust collar T12 ss 1100180200
112042-0000	1100120350	Shaft Nut. T12
112045-0000	1100120300	Thrust plate Assy. T12
112046-0000	1100120345	Clamp. V Band. T12
112047-0000	1100120150	O Ring. Seal Plate T12
112048-0000	1100120645	Nut. V Band clamp. T12

112049-0000	1100120610	Bolt. (Insert Plate) T12
112050-0000	1100120550	Lock plate (Insert Plate) T12
112060-0000	1100120155	O Ring B/Housing to C/Hsg T12
112061-0000	1100120480	Clamp plate, Turb. Side T12
112064-0000	1100120600	Bolt. Turb. Side TE06 / T12
112072-0000	1100120520	Lock plate, Turb. Side. TE06 / T12
112098-0000	1100120753	Service Kit T12 (minor) Smooth Bore
112121-0000	1100120340	Heat Shroud T12 Stamped
112202-0000	1100120708	Core Assy T1218
112242-0000	1100120350	Shaft Nut. T12
112342-0000	1100120350	Shaft Nut. T12
113133-0000	1401404170	Piston Ring (C) TC04, TD04, TE04H
114030-0000	1250404140	Snap Ring
114038-0000	1100300200	Thrust Collar (T30)
115005-0000	1450052750	Service Kit RHB52 (Short Brg)
115026-0000	1450052100	Bearing (Short 6mm) RHB5
115032-0000	1450052175	Piston Ring (Comp Small) RHB5
115033-0000	1450052170	Piston Ring (Comp Large) RHB5
115034-0000	1450052160	Piston Ring (Turbine End) RHB5 (USA P/N)
115052-0000	1450052320	Thrust Bearing (RHB5)
118001	1100180701	C.H.R.A. T1817,67
118001-0000	1100180701	C.H.R.A. T1817,67
118003	1100180700	C.H.R.A. T1810,18
118003-0000	1100180700	C.H.R.A. T1810,18
118010-0000	1100180435	Shaft & Wheel
118015-0000	1100180400	Comp. Wheel T1817
118016-0000	1100180401	COMPR WHEEL T1810
118020-0000	1100180340	Turbine Back Plate T18
118030-0000	1100180140	Snap Ring.
118032-0000	1100180161	Piston Ring T18 Smooth Bore
118033-0000	1100045170	Piston Ring TA45/ TA51/T18 /T 12 /T 6 C/E
118034-0000	1100180160	Piston Ring T18 S/B
118036-0000	1100180220	THRUST SPACER T18A/TV71-81
118038-0000	1100180202	Thrust Collar (T18)
118039-0000	1101061200	Thrust Collar (TV61-81 T18A)ssb 118239-0000
118042-0000	1100180350	Nut
118044-0000	1100180300	Thrust Plate (T18)
118047-0000	1100180150	O RING
118049-0000	1100120610	Bolt. (Insert Plate) T12
118050-0000	1100180550	Lock Plate T18
118052-0000	1100180320	Thrust Washer T12 ssb 118252
118053-0000	1100180195	Pin (Bearing Housing) Roll pin Type
118060-0000	1100180155	O Ring T18
118062-0000	1100180610	Bolt (Comp end)
118064-0000	1100180500	CLAMP PLATE
118065	1100180580	LOCKWASHER 5/16"
118065-0000	1100180580	LOCKWASHER 5/16"
118070-0000	1100180600	Bolt Turbine
118072-0000	1100180520	LOCKPLATE TURB
118099-0000	905	Gasket Kit T12 Dual Throat (3 Gaskets)
118135-0000	1100180222	Spacer Sleeve
118139-0000	1101083200	Thrust Collar (T18A - TV83)
118235-0000	1100180221	Spacer Sleeve (T18)
118239-0000	1101061200	Thrust Collar (TV61-81 T18A)ss 118039-0000
118242-0000	1100180350	Nut
118247-0000	1100181150	O RING
118249-0000	1100181550	Lock Tab (Back Plate)
118252-0000	1100180320	Thrust Washer T12ss 118052
118328-0000	1100180190	Wear Washer (Bearing) T12 / T18
118442-0000	1100180350	Nut
118526-0000	1100180775	Bearing Kit (1 Brg & 1 Washer)
118534-0000	1100180180	Piston Ring T18 T/E +.010"
118600-0000	1100180117	Bearing T12/T18 StdOD/- .005ID Bronze
118601-0000	1100180127	Bearing T18 Std OD/ -.010" ID
118603-0000	1100180114	Bearing T12/T18 +.005OD/Std ID Bronze NO Plateing
118604-0000	1100180110	Bearing T12/T18 +.005"OD/- .005"ID Bronze NO Plateing
118607-0000	1100180124	Bearing T12/T18+.010"OD/StdID Bronze NO Plateing
118609-0000	1100180120	Bearing T12/T18 +.010"OD/- .010"ID Bronze NO Plateing
118626-0000	1100180100	Bearing OD. Std / ID Std. T12 / T18 (Bronze)118626
125026-0000	1401404100	Bearings (TD04) Std.

125026-0001	1401404100	Bearings (TD04) Std.(pro94-01)
125034-0002	1401405160	Piston Ring TC05 / 6 T/E
125052-0001	1401404320	Thrust Bearing (TDO4)
127026-0000	1301027101	Bearing (Grooved O.D. K27)
127032-0000	1301027160	Piston Ring K26 Turb. & Comp.
127052-0000	1301027320	Thrust Bearing (K27)
127060-0000	1301026150	O Ring (K26) C/Hsg to S/ Plate
141026-0000	1152301100	Bearing Std (H1C)
141307	1152301120	Bearing HC1 +.010" OD / -.010" ID
141307-0000	1152301120	Bearing HC1 +.010" OD / -.010" ID
141309	1152301120	Bearing HC1 +.010" OD / -.010" ID
141309-0000	1152301120	Bearing HC1 +.010" OD / -.010" ID
143005-0000	1250403701	Core Assy. 3LD-279
143006-0000	1150400172	Piston Ring
143007-0000	1150400160	Piston Ring (HCSKM) Stainless
143011-0000	1150403435	Shaft & Wheel 3LD (2x Piston Ring Grooves)
143013-0000	1250403435	Shaft / Wheel (1 groove)
143017-0000	1250403700	Core Assy. 3LD-9 /3LD-259
143018-0000	1150403701	Core Assy. 3LD-1
143019-0000	1150403700	Core assy Holset 3LD-9 Smooth Bore B/hsg tapped UNC & Ford
143020-0000	1150403701	Core assy Holset 3LD-1 Smooth Bore B/hsg tapped UNC & Ford
143023-0000	1150403450	Bearing Hsg. 3LD Ford
143026	1250403100	Bearing 3LD (Std) Requires Brg Retainer as well
143026-0000	1250403100	Bearing 3LD (Std) Requires Brg Retainer as well
143027-0000	1150403452	Bearing Housing 3LD (Smooth bore - metric)
143029-0000	1250403450	Bearing Housing 3LD (step bore)
143031-0000	1250403140	Snap Ring
143032-0000	1150400170	Piston Ring Stiff Ring
143034-0000	1150400160	Piston Ring (HCSKM)
143035-0000	1250403200	Flinger 3LD
143044-0000	1250403300	Insert Plate
143045-0000	1150513300	Insert Plate 3FJ/3LM
143046-0000	1250403645	V Clamp
143047-0000	1250403861	Turbine Housing 3LD Twin Entry- 6 bolt discharge- 5/16 x18UNC 2.24sq in
143048-0000	1250030150	O Ring (Insert HSKM)
143050-0000	1250403310	Oil Deflector 3LD
143053	1250403240	Thrust Ring 3LD
143053-0000	1250403240	Thrust Ring 3LD
143055-0000	1301027500	Clamp Plate (3LD/3LEP/K27 Comp.)
143056-0000	1250403802	Comp Cover 279 / 3LD1
143057-0000	1250403800	Comp Cover 259 / 3LD9
143069-0000	1150403704	Core Assy. 3LD-1
143080	1150403800	Comp Cover 279 / 3LD1
143132-0000	1152302160	Piston Ring (H1C/H2C/3FD/J) Turb.End
143144-0000	1150704300	Insert Plate 4LGK/HC3
143152-0000	1250403321	Thrust Bearing 3LM
143207-0000	1150403750	Repair Kit 3LD
143215-0000	1250403426	Comp Wheel 3LD 279 -1
143217-0000	1250403425	C/Wheel 259 / 3LD9
143226	1150413100	Bearing 3FD/FJ ODStd/IDStd
143226-0000	1150413100	Bearing 3FD/FJ ODStd/IDStd
143232-0000	1150413160	Piston Ring 3LD/3LDA/3LM/S3A
143532-0000	1152302170	Piston Ring (H1C-H2C) Comp End
144021-0000	1250404340	Heat Shield
144026-0000	1250040100	Bearing (4LE- HC3 -HT3B -K361) Std OD/ Std ID
144027-0000	1250404100	Bearing 4B-D-V4HD-4MD Std OD/ Std ID With grooved ends & Grooved inside Dia
144030-0000	1301036140	Snap Ring (H.S.K)
144033	1250804240	Thrust Ring 4HD
144033-0000	1250804240	Thrust Ring 4HD
144034-0000	1250404142	Snap Ring
144035-0000	1250040260	Oil Control Sleeve (4LE)
144036-0000	1301036220	Spacer Sleeve (4LE/K36)
144037-0000	1150504200	Flinger Sleeve 4LE 2 ring groove (MELETTx 2 parts)
144039-0000	1250404220	Spacer Sleeve
144040-0000	1250404200	Flinger Sleeve
144042	1250040350	Shaft nut (4LE/F/GK)
144042-0000	1250040350	Shaft nut (4LE/F/GK)
144043-0000	1250404350	Shaft Nut 4MD
144045-0000	1250404345	V Band Clamp T/Hsg 7" 4MD
144048-0000	1250040155	O Ring (4LE/F/GK) C/Hsg to B/Hsg

144052-0000	1250040320	Thrust Bearing (4L-/HC3/3LKS) ssb144254-0000
144054-0000	1250404250	Shim 0.003
144055-0000	1250404251	Shim 0.005"
144056-0000	1250404252	Shim 0.010"
144069	1301036240	THRUST RING 4LE/F/G/K. 4MF
144069-0000	1301036240	THRUST RING
144215-0000	1250040400	Comp Wheel 4LE 302 Radial
144220-0000	1250504401	Comp Wheel 4LE 504 Radial
144231-0000	1250404141	Snap Ring 4HD
144232-0000	1152303170	Piston Ring
144235-0000	1250404260	Oil Control Sleeve 4B, 4MD, 4HD
144242	1250040350	Shaft nut (4LE/F/GK)
144242-0000	1250040350	Shaft nut (4LE/F/GK)
144243-0000	1250404330	Spacer Plate
144244-0000	1250404300	Insert Plate 4MD 4HD
144245-0000	1250404346	V Band Clamp Assy Comp/Hsg 9"
144246-0000	1250404150	O Ring 4MD
144247-0000	1250404155	O Ring C/End 4MD
144250-0000	1250404630	Spring Washer, lock tab, Thrust bearing
144251-0000	1250404310	Oil Deflector 4MD
144253-0000	1250404320	Thrust Bearing 4MD
144254-0000	1250040320	Thrust Bearing (4L-/HC3/3LKS) ss144054-0000
144329-0000	1152302100	Bearing Std OD/ Std ID H2B/C/D ssb 145026-0000
144330	1152302124	Bearing H2B/C/D O/D +.010"/ID Std ssb 145107-0000
144330-0000	1152302124	Bearing H2B/C/D O/D +.010"/ID Std ssb 145107-0000
144331	1152302120	Bearing H2B/C/D O/D Std/ID -.010"
144331-0000	1152302120	Bearing H2B/C/D O/D Std/ID -.010" ssb 145101-0000
144332	1152302120	Bearing H2B/C/D O/D +.010"/ID -.010" ssb 145109-0000
144332-0000	1152302120	Bearing H2B/C/D O/D +.010"/ID -.010" ssb 145109-0000
144511-0000	1250404435	Shaft and Wheel 4MD
144515-0000	1250404402	Compressor Wheel 4MD-354
144516-0000	1250404411	C/W 4MD-755 also 4HD
144517-0000	1250404408	C/W 4MD-659
144518-0000	1250404404	Compressor Wheel 4MD-454
144519-0000	1250404409	C/W 4MD-754
144521-0000	1250404406	C/W 4MD-558
144522-0000	1250404405	C/W 4MD-458
144523-0000	1250404400	Compressor Wheel 4MD-351
144524-0000	1250404450	B/Hsg Oil inlet and outlet UNC without threaded mtg bosses on side
144525-0000	1250404451	B/Hsg Oil inlet and outlet M8-6H
144610-0000	1250404712	Core Assy 4MD-354
144611-0000	1250404716	Core Assy. 4MD-351
144612-0000	1250404717	Core Assy 4MD-454
144613-0000	1250404718	Core Assy. 4MD-754
145026	1152302100	Bearing Std OD/ Std ID H2B/C/D
145026-0000	1152302100	Bearing Std OD/ Std ID H2B/C/D
145030-0000	1152302140	SNAP RING H2C / 3LKS
145060-0000	1152302150	O'RING INSERT H2C
145061-0000	1152302480	CLAMP (T)
145065-0000	1152302500	CLMP (C)
145072-0000	1152302520	LOCKPLATE (T)
145101	1152302120	Bearing H2B/C/D O/D Std/ID -.010"
145101-0000	1152302120	Bearing H2B/C/D O/D Std/ID -.010"
145107	1152302124	Bearing H2B/C/D O/D +.010"/ID Std
145107-0000	1152302124	Bearing H2B/C/D O/D +.010"/ID Std
145109	1152302120	Bearing H2B/C/D O/D +.010"/ID -.010"
145109-0000	1152302120	Bearing H2B/C/D O/D +.010"/ID -.010"
145253-0000	1152302320	Thrust Bearing H2C
146032-0000	1152303170	Piston Ring HT4B
150009-0000	1200050428	Comp. Wheel (T46-T50-ST50-VT50)
150011-0000	1200050435	Shaft & Wheel (T50) ssb 1200050436
150012-0000	1200050436	Shaft & Wheel (T50) ss 1200050435
150021-0000	1200050340	Heat Shield (T50-ST50-VT50)
150024-0000	1200050450	Bearing Housing (T50-ST50-VT50)
150025-0000	1200050280	Heat Packing (Cummins ST/VT50)
150026-0000	1200050281	Fiber Insert (Cummins ST/VT50)
150027-0000	1200050100	Bearing (Cummins ST/ VT 50)
150032-0000	1200050170	Piston Ring (Comp) CummmST/VT50
150033-0000	1200050160	Piston Ring (Turb) CummmST/VT50
150037-0000	1200050127	Bearing T50 Std OD / -.010"ID

150042-0000	1250404350	Shaft Nut 4MD
150047-0000	1200050150	O Ring (Seal Plate)Cum ST/VT50
150048-0000	1200050155	O Ring (B/Hsg) Cummins ST/VT50
150054-0000	1200050600	Bolt (2 piece Clamp) ST/VT50
150055-0000	1200050640	Lock Nut(2 piece clamp plate)
150060-0000	1200050156	O Ring C/Hsg (Cumm ST/VT50)
150310-0000	1200050750	Service Kit T-ST-VT 50 Cum Lrg
150314-0000	1200050751	Service Kit T-ST-VT 50 Cum Sml
150415	1200046425	Comp Wheel (T46 / T46B)
150415-0000	1200046425	Comp Wheel (T46 / T46B)
150416	1200046426	Comp Wheel (T46 / T46B)
150416-0000	1200046426	Comp Wheel (T46 / T46B)
150417	1200046427	Comp Wheel (T46 / T46B)
150417-0000	1200046427	Comp Wheel (T46 / T46B)
150424-0000	1200046450	Bearing Housing (CumminsT46B)
150501-0000	1200050700	Core Assy ST50/VT50
150502-0000	1200050701	Core Assy T50
150507-0000	1200050700	Core Assy ST50/VT50
150516-0000	1200050425	Comp. Wheel (T46-T50-ST50-VT50)
150518-0000	1200050426	Comp. Wheel (T46-T50-ST50-VT50)
150519-0000	1200050427	Comp. Wheel (T46-T50-ST50-VT50)
150520	1200050429	C/Wheel T50 / ST50
150520-0000	1200050429	C/Wheel T50 / ST50
150532-0000	1200050185	Piston Ring C/E +.010"
150533-0000	1200050180	Piston Ring (Comp End +.010" OD)
150534-0000	1200050181	Piston Ring T/E Std OD/ -.025"Width
150536-0000	1200050200	Thrust Spacer (Super Back) T50
150544-0000	1200050300	Insert Seal Plate (S/Back) T50
150933-0000	1200050184	Piston Ring (Cummins) OD +.010" / +.010" Wider
150934-0000	1200050183	Piston Ring (Cummins) Std OD / +.010" Wider
150951-0000	1200050345	COUPLING, V-BAND
160002-0000	1100180220	THRUST SPACER T18A/TV71-81
160003-0000	1101461550	Lock Plate TV series
160025-0000	1101672450	Bearing Housing TV61/71/81
160032-0000	1100045160	Piston Ring Step Bore(T12/45/51/TV)
160046-0000	1101680345	Clamp (V Band) TV61
160532-0000	1100045180	Piston Ring T60/T45/ T12 TV Turbine end (.833" .062")
170025-0000	1101671450	Bearing Housing TV7
180002-0000	1101081702	C.H.R.A TV/TW8106
180006-0000	1101081703	C.H.R.A. TV/TW8106
180009-0000	1101081701	C.H.R.A. TV8102
180010-0000	1101081700	C.H.R.A. TV8101
180011-0000	1101081435	SHFT & WHL TV81
180013-0000	1101081402	Comp. Wheel TV8102
180015-0000	1101081401	Comp. Wheel TV8101,4
180016-0000	1101881401	Comp. Wheel TW8106
180017-0000	1101881400	Comp. Wheel TV8107
180019-0000	1101081403	C/W TV8108
180021-0000	1101680340	Heat Shield (Cast) use Stamped180021-0000
180024-0000	1101081707	C.H.R.A TV/TW8112
180025-0000	1101081706	CHRA TV/TW8110
180043-0000	1101680360	PLATE ASSY TV81
180044-0000	1101670360	BACKPLATE TV7201
180045-0000	1101680361	SEAL PLATE
180046-0000	1101680346	CLAMP CMP TV81
180121-0000	1101680340	Heat Shield, (Cast)
180213-0000	1101081436	S/W TV8108
183011-0000	1101083435	Shaft & Wheel TW83
188104	1200050752	Service Kit T-ST-VT 50 Cum MajorKit (Inc. B/Hsg)
188104-0000	1200050752	Service Kit T-ST-VT 50 Cum MajorKit (Inc. B/Hsg)
188207	1250403753	Repair Kit 3LD/J
188207-0000	1250403753	Repair Kit 3LD/J
188400-0000	1101280750	Repair Kit TV6/7/8
188401-0000	1100040750	Service Kit TO4B
188402-0000	1100120753	Service Kit T12 (minor) Smooth Bore
188407	1100180752	Cartridge Repair Kit T18
188407-0000	1100180752	Cartridge Repair Kit T18
188411-0000	1100120753	Service Kit T12 (minor) Smooth Bore
210017-0000	1900000003	Gasket. Turb. Inlet Twin Entry T12
210018-0000	1900000025	Gasket. Oil Outlet T12

210019-0000	1900000035	Gasket. Oil Inlet T12
210021	1900000027	Gasket Oil Outlet T04B
210023-0000	1900000037	Gasket (Oil Inlet) T04B
210085-0000	1900000001	Gasket (Turb. 4 bolt) ST/VT50
210086-0000	1900000002	Gasket (Turb. 6 bolt) ST/VT50
210830-0000	1100180750	Repair Kit (Seal Plate) T12 / T18 (T/Brg + 3 Pins)
273178	1150403750	Repair Kit 3LD
310004-0000	1250403561	Bolt
310110-0000	1200050630	WASHER
310120-0000	1100120645	Nut. V Band clamp. T12
400100-0000	1100120350	Shaft Nut. T12
400105-0000	1250404140	Snap Ring
400132-0301	1100040560	BOLT
400140-0313	1100180580	LOCKWASHER 5/16"
400227-0000	1100040140	Snap Ring (thin)
400353-0013	1401404140	Snap Ring (TD04)
400355-0000	1100120645	Nut use 1100120645
400379-0000	1100180350	Shaft Nut Nut (use 118242.0000)
400390-0000	1100120350	Shaft Nut. T12
400405-0000	1100180620	Bolt (Thrust plates)
400405-0001	1100120610	Bolt. (Insert Plate) T12
400408-0000	1100180140	Snap Ring.
400424-0000	1100040150	O Ring (B/Hsg TO4B)
400424-0001	1100181150	O RING
400448-0000	1100180600	Bolt Turbine
400448-0001	1100120600	Bolt. Turb. Side TE06 / T12
400450-0001	1100040560	Bolt (TO4B)
400500-0685	1100120345	Clamp. V Band. T12
400515-0212	1100120645	Nut. V Band clamp. T12
400544-0000	1100040350	Shaft Nut (TO4B T3 RHT)
400560-0685	1100120345	Clamp. V Band. T12 use 112046-0000
400560-0775	1101680346	CLAMP CMP TV81
400568-0000	1100040140	Snap Ring (thin)
400572-0303	1100180610	Bolt (Comp end)
400579-0560	1101680345	Clamp (V Band) TV61 use 1101680345
400579-0560	1101068345	"V" Band Clamp TV Series
400580-0000	1100120645	Nut. V Band clamp. T12
400624-0000	1100180195	Pin (B/Hsg) Roll Pin (For solid pin use 400705.0000)
400637-0560	1101680345	Clamp (V Band) TV61
400637-5560	1101068345	CLAMP TURB TV61
400650-0001	1100180580	LOCKWASHER 5/16"
400674-0616	1100030561	Bolt T3 Metric (Seal Plate to B/Hsg) Micro encapsulated
400677-0816	1301027600	Bolt (K27/T3 Turbine HT)
400705-0000	1100180195	Pin (B/Hsg) Solid Pin (For roll pin use 400624.0000)
400720-0685	1100120345	Clamp. V Band. T12
400745-0410	1100025620	Screw Thrust Brg Ret. T2/T25 (Micro Encapsulated)
400749-0006	1100025160	Piston Ring T15 / T2/ T25 Turbine End
400768-0011	1100040350	Shaft Nut (TO4B T3 RHT)
400768-0012	1100120350	Shaft Nut. T12
400768-0013	1100180350	Shaft Nut Nut
400781-0702	1101680620	BOLT
400785-0685	1100120345	Clamp. V Band. T12
400785-0775	1101680346	CLAMP CMP TV81
400785-5560	1101680345	Clamp (V Band) TV61
400805-0202	1250403561	Bolt
400810-0410	1100025620	Screw Thrust Brg Ret. T2/T25 (Micro Encapsulated)
400811-0000	1100120645	Nut. V Band clamp. T12
402046-0000	1100300200	Thrust Collar (T30)
402588-0000	1100180320	THRUST WASHER
403069-0010	1100180150	O RING
403069-0012	1100120155	O Ring B/Housing to C/Hsg T12
403069-0023	1100120150	O Ring. Seal Plate T12
403069-0024	1100180155	O Ring T18
403069-0050	1100180150	O RING
403069-0051	1100120150	O Ring. Seal Plate T12
403069-0069	1100045155	O Ring Seal Plate to C/Hsg T45
403069-0155	1401404150	O Ring (Seal Plate TD04)
403069-0156	1401404155	O Ring (TD04 B/Hsg / Chsg)
403069-0163	1100025150	O Ring (Insert / Seal Plate T2 / T25)
403818-0000	1100045170	Piston Ring TA45/ TA51/T18 /T 12 /T 6 C/E

403818-0002	1100120160	PISTON RING
403818-0007	1100120160	PISTON RING
403818-0008	1100120160	PISTON RING
403818-0009	1100040170	Piston Ring T04B C/E
403818-0015	1100120160	Piston Ring Smooth Bore T12
403818-0016	1100180161	Piston Ring T18 Smooth Bore
403818-0018	1100180161	Piston Ring T18 Smooth Bore
403818-0024	1100180161	Piston Ring T18 Smooth Bore
403818-0030	1100045160	Piston Ring Step Bore(T12/45/51/TV)
403818-0031	1100180160	Piston Ring T18 S/B
403818-0034	1100040160	Piston Ring T04B(Step.Turb)
403818-0047	1100045170	Piston Ring TA45/ TA51/T18 /T 12 /T 6 C/E
404169-0000	1100180550	Lock Plate T18
404223-0000	1100181520	Lock Plate TE
404375-0000	1100180500	CLAMP PLATE
404470-0000	1101061200	Thrust Collar (TV61-81 T18A)use1101061200
404470-0001	1101083200	Thrust Collar (T18A - TV83)ssb444834-0001
404470-0002	1100180200	Thrust collar T12ss 407484-0001 (ss 406499-0001 in service)
404805-0001	1100180401	COMPR WHEEL T1810
404955-0001	1100180400	Comp. Wheel T1817
405155-0000	1100120221	Spacer Sleeve (T12) ssb 1100060200
405157-0000	1100120550	LOCK
405157-0001	1100120550	Lock plate (Insert Plate) T12
405861-0003	1100040110	Bearing +.005"OD/-.005"ID (Bronze Lead-Tin Plated)
405875-0011	1100180110	Bearing T12/T18 +.005"OD/-.005"ID Aluminium
405919-0001	1100040117	Bearing Std OD/ .005" ID Bronze
405919-0002	1100040127	Bearing T3/T04B OD std/ ID -.010"
405919-0003	1100040110	Bearing +.005"OD/-.005"ID (Bronze Tin Plated)
405919-0004	1100040120	Bearing +.010" OD / -.010" ID
405919-0005	1100040114	Bearing OD +.005"/Std ID
405919-0006	1100040124	Bearing T04B OD +.010"/Std ID
405919-0013	1100040110	Bearing +.005"OD/-.005"ID (Bronze Tin Plated)
405919-0017	1100040130	Bearing T3/T04B +.005"OD/-.010"ID
405936-0001	1100180114	Bearing T12/T18 +.005OD/Std ID Bronze
405936-0002	1100180117	Bearing T12/T18 StdOD/-.005ID Bronze
405936-0003	1100180124	Bearing T12/T18+.010"OD/StdID Bronze NO Plateing
405936-0004	1100180127	Bearing T18 Std OD/ -.010" ID Bronze
405936-0011	1100180110	Bearing T12/T18 +.005"OD/-.005"ID Bronze NO Plateing
405936-0012	1100180120	Bearing T18 +.010"OD/-.010"ID
406012-0000	1100180520	LOCKPLATE TURB
406063-0000	1100120480	Clamp plate, Turb. Side T12
406064-0000	1100120520	Lock plate, Turb. Side. TE06 / T12
406156-0004	1100120400	Comp. Wheel TE06 / T1210
406286-0001	1100120700	Core Assy T1210
406308-0000	1100120300	Thrust plate Assy. T12 Use 1100120300
406476-0008	1100120402	Comp. Wheel TE06 / T1227
406499-0001	1100180201	Thrust collar TE06 / T12 Use with 1100120221 ssb 404470-0002 in service
406499-0002	1100180202	Thrust Collar (T18)
406702-0000	1100040100	Bearing (T3/T04B) Standard (Alum)
406834-0002	1100120300	Thrust plate Assy. T12
406845-0001	1100120435	Shaft & Wheel T12
406845-0005	1100120436	Shaft & Wheel T12
406845-0007	1100120435	Shaft & Wheel T12 (use 1100120435)
406866-0003	1100120455	Bearing Housing T12
406866-0004	1100120450	Bearing Housing T12
406867-0001	1100120700	Core Assy T1210
406867-0008	1100120700	Core Assy T1210
406902-0000	1100040100	Bearing (T3/T04B) Standard (Alum)
406906-0000	1100040200	Thrust Collar (Dynamic T04B) SSB 1100040203 / 444506-0002
406906-0099	1100040200	Thrust Collar (Dynamic T04B) SSB 1100040203 / 444506-0001
406907-0000	1100040320	THRUST BEARING (T04B 3 Hole)
406907-0001	1100040320	Thrust Bearing (T04B 3 Hole)
406908-0001	1100040480	CLAMP PLATE TURB
406908-0002	1100040480	Clamp Plate (T04B Turb)
406909-0000	1100040520	Lock Plate (T04B Turb.)
406967-0000	1100180220	THRUST SPACER T18A/TV71-81
406967-0001	1100180220	THRUST SPACER T18A/TV71-81
407134-0000	1100180100	Bearing OD. Std / ID Std. T12 / T18
407135-0000	1100180190	Wear Washer (Bearing) T12 / T18
407318-0001	1100180435	Shaft & Wheel

407329-0002	1100180701	C.H.R.A. T1817,67 (Old smooth bore) use 407329-0052
407329-0013	1100180700	C.H.R.A. T1810,18
407329-0014	1100180701	C.H.R.A. T1817,67
407329-0016	1100180700	C.H.R.A. T1810,18
407329-0018	1100180701	C.H.R.A. T1817,67
407329-0051	1100180700	C.H.R.A. T1810,18 (old Service Cart. Rep.by 407329-0013)
407329-0052	1100180701	C.H.R.A. T1817,67
407329-0063	1100180700	C.H.R.A. T1810,18 (Rep.by 407329-0013)
407329-0064	1100180701	C.H.R.A. T1817,67
407432-0000	1100180100	Bearing OD. Std / ID Std. T12 / T18
407484-0001	1100180200	Thrust collar T12ssb 404470-0002
407485-0001	1100120220	Thrust Spacer (T12) ssb 1100060200
407505-0002	1100120701	Core Assy T1224 Smooth bore (Obs) Use 112002
407505-0005	1100120702	Core Assy T1227 Smooth bore (Obs) Use 112003
407505-0006	1100120708	Core Assy T1218
407505-0009	1100120706	Core Assy T1231
407505-0013	1100120703	Core Assy T1237
407505-0014	1100120704	Core Assy T1238
407505-0015	1100120701	Core Assy T1224
407505-0016	1100120702	Core Assy T1227
407505-0017	1100120708	Core Assy T1218
407505-0018	1100120705	CHRA T1226
407505-0020	1100120700	Core Assy T1210
407505-0056	1100120708	Core Assy T1218
407505-0057	1100120708	Core Assy T1218
407505-0064	1100120704	Core Assy T1238
407505-5009	1100120706	Core Assy T1231
407505-9015	1100120701	Core Assy T1224 Rebuild Cat 8S6833 New 7N7248
407574-0002	1100120340	Heat shroud T12 Use 112121
407577-0002	1101461550	Lock Plate TV series
407634-0000	1100040320	Thrust Bearing (TO4B 2 Hole)Can Use 1100040320)
407634-0002	1100040320	THRUST BEARING (TO4B 2 Hole)
407648-0001	1100181550	Lock Tab (Back Plate)
407657-0004	1101680340	Heat Shield, (Cast)
407737-0000	1100180340	Turbine Back Plate T18
407778-0001	1100120340	Heat shroud T12 Use 112121
407875-0000	1100040500	Clamp Plate (TO4B Comp.)
407876-0000	1100040540	Lock Plate (TO4B Comp.)
407884-0001	1100120751	Service kit (T12) Smooth Bore
408045-0006	1100040360	Seal Plate T04B Dynamic
408045-0034	1100040360	Seal Plate T04B Dynamic ssb 408045-0051
408045-0051	1100040360	Seal Plate T04B Dynamic
408049-0003	1100120160	Piston Ring Smooth Bore T12
408049-0004	1100045160	Piston Ring Step Bore(T12/45/51/TV)
408049-0006	1100180161	Piston Ring T18 Smooth Bore
408049-0008	1100180160	Piston Ring T18 S/B
408049-0009	1100040160	Piston Ring TO4B(Step.Turb)
408049-0013	1100040161	Piston Ring T(T3/T04B Stiff)
408049-0023	1100045160	Piston Ring Step Bore(T12/45/51/TV)
408056-0000	1100040100	Bearing (T3/TO4B) Standard (Bronze)
408056-0001	1100040100	Bearing (T3/TO4B) Standard (Bronze Tin plated)
408126-0006	1100120401	Comp. Wheel T1224
408126-0014	1100120400	Comp. Wheel TE06 / T1210
408126-0021	1100120402	Comp. Wheel TE06 / T1227
408178-0005	1100120403	Comp. Wheel T1233
408178-0009	1100120404	Comp. Wheel T1237
408178-0011	1100120405	Comp. Wheel T1238
408206-0002	1100040360	Seal Plate T04B Dynamic
408306-0000	1100180100	Bearing OD. Std / ID Std. T12 / T18 (Bronze)118626
408463-0002	1101081402	Comp. Wheel TV8102
408463-0004	1101081401	Comp. Wheel TV8101,4
408487-0002	1101680361	SEAL PLATE
408487-0013	1101680360	PLATE ASSY TV81
408487-0026	1101670360	BACKPLATE TV7201
408492-0012	1101081436	S/W TV8108 (use MEL 1101081436
408492-0014	1101081435	SHFT & WHL TV81
408492-0016	1101081436	S/W TV8108
408492-0017	1101081435	SHFT & WHL TV81(use 180011)
408492-0018	1101081436	S/W TV8108
408492-0021	1101081435	SHFT & WHL TV81

408492-0022	1101081436	S/W TV8108
408495-0010	1101672450	Bearing Housing (TV61/71/81use MEL1101672450)
408495-0024	1101671450	Bearing Housing TV7
408495-0028	1101672450	Bearing Housing (TV61/71/81use MEL1101672450)
408593-0000	1100180320	Thrust Washer T12 ssb 449886-0000
408597-0000	1101461550	Lock Plate use 1101461550
408662-0000	1100180222	Spacer Sleeve
408662-0001	1100180222	Spacer Sleeve
408742-0001	1101081700	C.H.R.A. TV8101
408742-0002	1101081701	C.H.R.A. TV8102
408742-0006	1101081703	C.H.R.A. TV/TW8106
408742-0007	1101081704	C.H.R.A TV/TW8107
408742-0008	1101081705	CHRA TV/TW8108
408742-0011	1101081707	C.H.R.A TV/TW8112
408742-0014	1101081706	CHRA TV/TW8110
408742-0018	1101081702	C.H.R.A TV/TW8106
408742-0020	1101081708	C.H.R.A. TV/TW8113/14
408742-5006	1101081703	C.H.R.A. TV/TW8106 use 408742-0006
408742-9001	1101081700	C.H.R.A. TV8101use 408742-0001
408742-9002	1101081701	C.H.R.A. TV8102 use 408742-0002
408742-9006	1101081703	C.H.R.A. TV/TW8106 use 408742-0006
408742-9007	1101081704	C.H.R.A TV/TW8107use 408742-0007
408742-9008	1101081705	CHRA TV/TW8108use408742-0008
408742-9011	1101081707	C.H.R.A TV/TW8112use408742-0011
408742-9014	1101081706	CHRA TV/TW8110use408742-0014
408742-9018	1101081702	C.H.R.A TV/TW8106use408742-0018
408742-9020	1101081708	C.H.R.A. TV/TW8113/14use 408742-0020
408768-0001	1100180220	THRUST SPACER T18A/TV71-81
408768-0002	1100180221	Spacer Sleeve (T18)
408768-0003	1100120220	Spacer Sleeve (TE06-T6010/T12) ss 1100120220&1
408774-0029	1101072700	Core Assy TW7204
408792-0000	1100040200	Thrust Collar (T3-TO4B) USE 1100040203
408906-0000	1100180775	Bearing Kit T18 (2 Brgs & 2 Washers)
408906-0007	1100180780	Bearing Kit T18 +.020"OD/Std ID
408906-0008	1100180781	Bearing Kit T18 +.020"OD/- .010 ID
408975-0000	1100180300	Thrust Plate (T18)
409026-0001	1900000037	Gasket (Oil Inlet) T04B
409036-0000	1900000037	Gasket (Oil Inlet) T04B / H2C
409037-0000	1900000027	Gasket Oil Outlet T04B
409038-0000	1900000003	Gasket. Turb. Inlet Twin Entry T12
409049-0002	1100040160	Piston Ring TO4B(Step.Turb)
409096-0001	1100030401	Comp. Wheel (T3) TA0301 ssb409096-0008
409096-0004	1100030403	Comp Wheel T3 TC0301 ssb 409096-0011
409096-0005	1100030402	Comp. Wheel (T3)
409096-0006	1100030400	Comp. Wheel (T3) Trim 60 ss 409096-0006
409096-0008	1100030401	Comp. Wheel (T3) TA0301ss 409096-0001
409096-0011	1100030403	Comp Wheel T3 TC0301 ss 409096-0004
409096-0013	1100030400	Comp. Wheel (T3) Trim 60 ss 409096-0006
409096-0014	1100030402	Comp. Wheel (T3)
409128-0001	1100040100	Bearing (T3/TO4B) Standard (Lead Bronze Tin plated)
409132-0001	1101881401	Comp. Wheel TW8106
409132-0002	1101881400	Comp. Wheel TV8107
409132-0004	1101081403	C/W TV8108
409132-0009	1101081400	Comp Wheel (TV81)
409179-0018	1100040400	Comp.Wheel (TO4B)
409266-0001	1900000037	Gasket (Oil Inlet) T04B
409266-0003	1900000035	Gasket. Oil Inlet T12
409267-0002	1900000025	Gasket. Oil Outlet T12
409282-0000	1100120753	Service Kit T12 (minor) Smooth Bore
409368-0000	1100120340	SHROUD
409558-0000	1100040202	Thrust Collar (TA31 Carb Seal)
409695-0000	1100030270	Carbon Seal T3/T04B
409794-0000	1101680340	Heat Shield (Cast) use Stamped180021-0000
409844-0002	1101481703	CHRA TL8113/14
409844-0005	1101481700	CHRA TL8106
409844-0009	1101481701	C.H.R.A TL8107
409844-9001	1101481702	CHRA TL8112 use 409844-0001
409844-9002	1101481703	CHRA TL8113/14 use 409844-0002
409844-9005	1101481700	CHRA TL8106 use 409844-0005
409844-9009	1101481701	C.H.R.A TL8107 use 409844-0009

410004-0000	1250403561	Bolt
410110-0000	1200050630	Washer (2 Piece clamp Plate)
410115-0000	1101680620	BOLT
410120-0000	1100120645	Nut. V Band clamp. T12
410165-0000	1350130620	Bolt insert Plate KTR130 Flat Back
410166-0000	1101461550	Lock Plate KTR130 (Insert plate Roto-Master No.)
410167-0000	1301027610	Bolt (K27/K33/H2C/Garrett S/P to C/Hsg)
410168-0000	1301027600	BOLT (T)
410212-0001	1101481450	Bearing Hsg.Water Cooled TL81
410249-0001	1100040100	Bearing (T3/TO4B) Standard (Lead Bronze)
410249-0006	1100040110	Bearing +.005"OD/-.005"ID (Bronze Lead-Tin Plated)
410393-0001	1100045320	Thrust Bearing TA45/TA51
410394-0001	1100045100	Bearing Std T45/51
410606-0005	1100180110	Bearing T12/T18 +.005"OD/-.005"ID Bronze Tin Plate
410775-0001	1100040100	Bearing (T3/TO4B) Standard
410775-0009	1100040100	Bearing (T3/TO4B) Standard (Bronze)
410775-0010	1100040100	Bearing (T3/TO4B) Standard (Bronze)
410775-0017	1100040100	Bearing (T3/TO4B) Standard (Bronze Tin plated)
410775-0018	1100040100	Bearing (T3/TO4B) Standard (Leaded Bronze Tin plated)
410775-0020	1100040100	Bearing (T3/TO4B) Standard (Bronze)
410801-0001	1100045220	Spacer Sleeve (T45)
413582-0002	1100030821	T/Hsing (TB0363)
413671-0000	1900000027	Gasket Oil Outlet T04B
413746-0001	1100030829	Turbine Housing TB0384
430026-0004	1100030822	Turbine Housing TB0341
430026-0012	1100030820	Turbine Housing TB0338 (A/R .48)
430064-0001	1100025140	Snap Ring. Brg Retain (T2/T25)
430093-0004	1100020100	Bearing Std. (Short T2/T25) (Leaded Bronze)
430093-0005	1100020100	Bearing Std. (Short T2/T25) Alum. Use 1100020100
430093-0006	1100020100	Bearing Std. (Short T2/T25) (Bronze Tin plated)
430093-0007	1100020124	Bearing T2 Narrow OD +.010"/ ID Std (Aluminum)
430093-0009	1100020131	Bearing T2 Narrow OD +.010"/ ID -.005" (Aluminum)
430093-0010	1100020124	Bearing T2 Narrow OD +.010"/ ID Std (Bronze)
430093-0012	1100020131	Bearing T2 Narrow OD +.010"/ ID -.005" (Bronze)
430093-0013	1100020124	Bearing T2 Narrow OD +.010"/ ID Std (Bronze Tin plated)
430093-0015	1100020131	Bearing T2 Narrow OD +.010"/ ID -.005" (Bronze Tin plated)
430093-0016	1100020100	Bearing Std. (Short T2/T25) (Bronze)
430093-0017	1100020100	Bearing Std. (Short T2/T25) (Bronze) ssb 430093-0016
430093-0018	1100020124	Bearing T2 Narrow OD +.010"/ ID Std (Bronze)
430093-0020	1100020131	Bearing T2 Narrow OD +.010"/ ID -.005" (Bronze)
430394-0011	1100030830	Turbine Housing TB0345
430394-0012	1100030820	Turbine Housing TB0338 (A/R .48)
430609-0030	1100020891	Turbine housing TB0203
430609-0040	1100020820	Turbine Housing (TB0208)
430609-0055	1100020827	Turbine Housing TB0223
430609-0056	1100020823	Turbine Housing (TB0210)
430609-0059	1100020824	Turbine Housing
430609-0063	1100020822	T/Hsing (TB0203)
430609-0094	1100020822	T/Hsing (TB0203)
430609-0099	1100025820	Turbine Housing TB2533
430609-0113	1100020825	Turbine Housing T2
430609-0132	1100025820	Turbine Housing TB2533
430609-0174	1100020828	Turbine Hsg Diesel TB02 806Evasion 605XM 306ZX Turbo No 454086-0001
430641-0001	1100030821	T/Hsing (TB0363)
430641-0001	1100030821	T/Hsing (TB0363)
430641-0002	1100030821	T/Hsing (TB0363)
430641-0002	1100030821	T/Hsing (TB0363)
430641-0012	1100030834	T/H TB03 A/R 0.48
430647-0032	1100030822	Turbine Housing TB0341
430647-0033	1100030822	Turbine Housing TB0341
432223-0003	1100030833	Turbine Housing (TB0353)
432223-0005	1100030825	Turbine Housing
432224-0001	1100030825	Turbine Housing
432224-0005	1100030825	Turbine Housing
432236-0001	1100025100	Bearing Std. (Long T2/T25) (Bronze Tin plated)
432236-0002	1100025100	Bearing Std. (Long T2/T25)
432236-0003	1100025100	Bearing Std. (Long T2/T25)
432236-0004	1100025100	Bearing Std. (Long T2/T25)
432236-0006	1100025117	Bearing T25 (Long) (OD Std / ID -.005") (Bronze Tin plated)
432236-0007	1100025124	Bearing T25 (Long) (OD +.010" / ID Std) (Bronze Tin plated)

432236-0008	1100025100	Bearing Std. (Long T2/T25) (Bronze)
432236-0010	1100025117	Bearing T25 (Long) (OD Std / ID -.005") (Bronze)
432236-0011	1100025124	Bearing T25 (Long) (OD +.010" / ID Std) (Bronze)
432254-0001	1100025320	Thrust Bearing T2/T25
432254-0002	1100025320	Thrust Bearing T2/T25
432261-0001	1100020200	Thrust Collar 3 bolt (Dynamic T2/T25)
435255-0001	1100025350	Shaft Nut T2/T25 Short boss LHT
435419-0001	1102015351	Shatf Nut 5mm Lht
435419-0002	1401404350	Shaft nut TD04 R/H/Thread
435493-0002	1100025821	Turbine Hsg Petrol TB025 806Evasion 605XM 306ZX Turbo p/n 454162-0001
435493-0003	1100025821	Turbine Hsg Petrol TB025 806Evasion 605XM 306ZX Turbo p/n 454162-0001
441083-0001	1101461550	Lock Plate TV series
441341-0002	1100030410	Comp. Wheel (T3) (.0002)
441411-0001	1100180100	Bearing OD. Std / ID Std. T12 / T18 (Bronze, no plating) T12/T18
441411-0002	1100180114	Bearing T12/T18 +.005OD/Std ID Bronze NO Plateing
441411-0003	1100180117	Bearing T12/T18 StdOD/- .005ID Bronze
441411-0004	1100180124	Bearing T12/T18+.010"OD/StdID Bronze NO Plateing
441411-0005	1100180127	Bearing T12/T18 Std OD/-.010"ID Bronze NO Plateing
441411-0006	1100180110	Bearing T12/T18 +.005"OD/- .005"ID Bronze NO Plateing
441411-0007	1100180120	Bearing T12/T18 +.010"OD/- .010"ID Bronze NO Plateing
441411-0009	1100180100	Bearing OD. Std / ID Std. T12 / T18
441411-0011	1100180117	Bearing T12/T18 StdOD/- .005ID Bronze
441411-0012	1100180124	Bearing T18 +.010" OD/Std ID
441411-0013	1100180127	Bearing T18 Std OD/ -.010" ID
441411-0015	1100180120	Bearing T18 +.010"OD/- .010"ID
441575-0000	1900120790	Gasket Kit T12 Single entry
441843-0001	1100180100	Bearing OD. Std / ID Std. T12 / T18
441903-0002	1101063220	Spacer Sleeve (TV63-83)
441904-0002	1101073200	Thrust Collar (TV73 - TV83)
441934-0000	1101091200	Thrust Collar (TV91)
442029-0014	1101083435	Shaft & Wheel TW83
442029-0017	1101083435	Shaft & Wheel TW83
442029-0018	1101084435	S/W
442030-0001	1101685320	Thrust Bearing TV75
442479.0002	1101078435	Shaft & Wheel TV78
443218-0000	1100180195	PIN
44345-0775	1101680346	CLAMP CMP TV81 use 1101680346
443454-0560	1101680345	CLAMP TURB TV61 use 160046.0000
443454-0685	1100120345	Clamp. V Band. T12
443686-0001	1101685320	Thrust Bearing TV75
443792-0001	1101092200	Thrust Collar (TW92)
443852-0001	1100025201	Thrust Collar(Dynamic T2/T25)
443852-0002	1100025200	Thrust Collar (Dynamic T2/T25)
444027-0001	1100030828	Turbine Housing TB0361
444101-0202	1100040561	Bolt (Micro Enc. Seal Plate)
444385-0001	1100030834	T/H TB0370 A/R 0.48
444385-0002	1100030893	Turbine Housing TB0386
444428-0001	1100025140	Snap Ring. Brg Retain (T2/T25)
444506-0001	1100040203	Trust Collar T04B ss 1100040200/1100040201
444506-0001	1100040200	Thrust Collar (Dynamic T04B) SSB 1100040203 ss406906-0099 (2x8 holes smooth ends)
444506-0002	1100040200	Thrust Collar (Dynamic T04B) ss 406906-0000 (2X8 holes blasted end) T3-T04
444506-0004	1100040200	Thrust Collar (Dynamic T04B) use 1100040203
444506-0005	1100040200	Thrust Collar (Dynamic T04B) use 1100040203
444723-0001	1101481450	Bearing Hsg.Water Cooled TL81
444827-0001	1101881401	Comp. Wheel TW8106
444827-0002	1101881400	Comp. Wheel TV8107
444827-0004	1101081403	C/W TV8108
444834-0000	1101061200	Thrust Collar (TV61-81 T18A)ss404470-0000
444834-0001	1101083200	Thrust Collar (T18A - TV83)
444834-0002	1100120200	Thrust collar (TE06 - T12) 1100120200
445421-0001	1102015170	Piston Ring (Comp. End T15)
446397-0560	1101680345	Clamp (V Band) TV61use 1101680345
446401-0775	1101680346	CLAMP CMP TV81 use 1101680346
446401-5560	1101680345	Clamp (V Band) TV61 use 1101680345
446401-5685	1100120345	Clamp. V Band. T12 use 112046-0000
446451-0000	1101045200	Thrust Collar (TV 45)
449886-0000	1100180320	Thrust Washer T12 ss 408593-0000
465142-0001	1100030821	T/Hsing (TB0363)
465142-0002	1100030821	T/Hsing (TB0363)

465142-0003	1100030821	T/Hsing (TB0363)
466644-0011	1100030831	Turbine Housing TB0345
466868-0001	1100030827	Turbine Housing TA0316
466868-0002	1100030827	Turbine Housing TA0316
468002-0001	1100040117	Bearing Std OD/ .005" ID(Alum)
468002-0002	1100040127	Bearing T3/T04B OD std/ ID -.010"(Alum)
468002-0003	1100040110	Bearing +.005"OD/-.005"ID (Alum)
468002-0004	1100040120	Bearing +.010" OD / -.010" ID (Alum)
468002-0005	1100040114	Bearing OD +.005"/Std ID (Alum)
468002-0006	1100040124	Bearing TO4B OD +.010"/Std ID (Alum)
468013-0000	1100040100	Bearing Kit Std OD/ Std ID Bronze (Note Kit 2 brgs)
468100-0000	1100040750	Service Kit TO4B
468103-0000	1101280750	Repair Kit TV6/7/8
468105-0000	1100060750	TE06 Service Kit
468107-0000	1100181750	T18A Service Kit
468108-0000	1100120753	Service Kit T12 (minor) Smooth Bore
468109-0000	1100120753	Service Kit T12 (minor) Smooth Bore
468112-0000	1100180751	Repair Kit T18 (Step Bore)
468173-0000	1101280750	Repair Kit TV6/7/8
468177-0000	1100120753	Service Kit T12 (minor) Smooth Bore
468178-0000	1100180752	Cartridge Repair Kit T18
468190-0000	1900120791	Gasket set use 118099-0000
707937-0001	1302003751	K03/K04 Repair Kit
709365-0001	1100040751	Repair Kit 360Deg T/Brg T3/4Dyn (Ford Motorsport)



HOLSET - MELETT Cross Reference

To quickly find a part, use the ctrl+F option. If the part you require is not found, please contact Melett direct with you enquiry.

Melett Ltd

Tel: +44 (0)1924 488686

Fax: +44 (0)1924 459200

Email: sales@melett.com

Melett 2002. All manufacturers names, numbers, symbols and descriptions used herein are for reference purposes only and do not imply that any part listed is the product of these manufacturers.

Holset Part No.	MELETT Part No	DESCRIPTION
13070	1250404100	Bearing 4B-D-V4HD-4MD Std OD/ Std ID With grooved ends & Grooved inside Dia
13073	1250404140	Snap Ring
15155	1250404200	Flinger Sleeve
15160	1100120610	Bolt. (Insert Plate) T12
15173	1250404346	V Band Clamp Assy Comp/Hsg 9"
15174	1250404345	V Band Clamp T/Hsg 7" 4MD
15178	1250404340	Heat Shield
15180	1100120610	Bolt. (Insert Plate) T12
15186	1100120645	Nut. V Band clamp. T12
15187	1100180610	Bolt (Comp end)
15189	1250404250	Shim 0.003
15190	1250404251	Shim 0.005"
15191	1250404252	Shim 0.010"
15192	1250404630	Spring Washer, lock tab, Thrust bearing
15193	1250404240	Thrust Ring 4MD
15194	1250404220	Spacer Sleeve
16407	1250404402	Compressor Wheel 4MD-354
16407?	1250404403	Compressor Wheel 4MD-354 (Hol 4B)
16409?	1250404400	Compressor Wheel 4MD-351 (Hol 4")
16569	1250404350	Shaft Nut 4MD
16575	1250404900	Noz Ring 4MD (.318)
16577	1250404901	Noz Ring 4MD (.246)
18364?	1250404407	C/W 4MD-654 (Hol 4")
18366	1250404409	C/W 4MD-754
18366?	1250404410	C/W 4MD-754 4"
18373	1250404142	Snap Ring
18455	1301036220	Spacer Sleeve (4LE/K36)
18465	1250404861	T/Hsg 6Hole out UNC
18493	1250404141	Snap Ring 4HD
18494	1250404300	Insert Plate 4MD 4HD
18497	1250404310	Oil Deflector 4MD
18499	1250404150	O Ring 4MD
20051	1250404630	Spring Washer, lock tab, Thrust bearing
20120	1250404260	Oil Control Sleeve 4B, 4MD, 4HD
20936	1250404320	Thrust Bearing 4MD
20937	1250804240	Thrust Ring 4HD
20938	1250404330	Spacer Plate
20940	1250040350	Shaft nut (4LE/F/GK)
20987	1250404155	O Ring C/End 4MD
22366	1250040100	Bearing (4LE- HC3 -HT3B -K361) Std OD/ Std ID
22447	1150400160	Piston Ring (HCSKM)
23828	1250404901	Noz Ring 4MD (.246)
23839	1250040260	Oil Control Sleeve (4LE)
23845	1250030150	O Ring (Insert HSKM)
23863	1250403140	Snap Ring

23937	1250404411	C/W 4MD-755 also 4HD
25233	1250404450	B/Hsg Oil inlet and outlet UNC without threaded mtg bosses on side
25279	1250403240	Thrust Ring 3LD
25393	1250404710	Core Assy 4MD-659
25398	1250404711	Core Assy 4MD-558
25489	1250404800	Comp. Hsg
2575686	1100025181	Piston ring T/E T2 T25 +.010width
27028	1250404412	C/W 4MD-757
27046	1250404405	C/W 4MD-458
27047	1250404406	C/W 4MD-558
3426674	1100040114	Bearing OD +.005"/Std ID (Bronze NO Tin plating)
3500168	1152301751	Repair Kit (Full) H1B
3500433	1152303435	Shaft & Wheel (HC3/K361) UNF T3
3501552	1301027610	Bolt (K27/K33/H2C/Garrett S/P to C/Hsg)
3501819	1152301751	Repair Kit (Full) H1B
3502017	1152302480	Clamp Plate (H2C Turb)
3502413	1152303435	Shaft & Wheel (HC3/K361) UNF T3
3502449	1152301150	O Ring (B/H-S/P H1C> H2A HC5A)
3502499	1152303436	Shaft & Wheel (HC3 UNF T2)
3502734	1152302500	Clamp plate (H2C Comp)
3502817	1152303436	Shaft & Wheel (HC3 UNF T2)
3503023	1152303435	Shaft & Wheel (HC3/K361) UNF T3
3503100	1152301100	Bearing Std (H1C)
3504413	1152302100	Bearing Std OD/ Std ID H2B/C/D
3518579	1150400160	Piston Ring (HCSKM)
3518595	1150400160	Piston Ring (HCSKM)
3518980	1152301240	Thrust ring / Spacer H1C-D-E
3519318	1152303320	Thrust Bearing 4LEG (Ramped)
3519318	1250040320	Thrust Bearing (4L-/HC3/3LKS 4MF) Taper Land ss 59513
3519762	1900000037	Gasket (Oil Inlet) 4LE
3519763	1900000025	GASKET
3519807	1900000027	Gasket Oil Outlet T04B
3521225	1301027600	Bolt (K27/T3 Turbine HT)
3521441	1150400160	Piston Ring (HCSKM)
3521442	1152303170	Piston Ring HT4B
3523164	1250040120	Bearing 4L +0.010" OD/-0.010"ID
3523613	1152302320	Thrust Bearing H2C
3524754	1100040100	Bearing (T3/TO4B) Standard
3524769	1100040150	O Ring (B/Hsg TO4B)
3524770	1100040320	THRUST BEARING
3524771	1100040160	Piston Ring TO4B(Step.Turb)
3524772	1100040170	Piston Ring T04B C/E
3524774	1100040350	Shaft Nut (TO4B T3 RHT)
3524775	1100040540	Lock Plate (TO4B Comp.)
3524776	1100040520	Lock Plate (TO4B Turb.)
3524778	1100040560	BOLT
3524779	1250403561	Bolt
3524780	1100040500	Clamp Plate (TO4B Comp.)
3524781	1100040480	CLAMP PLATE TURB
3524796	1100040750	Service Kit TO4B
3524887	1100040400	Comp.Wheel (TO4B)
3525402	1100040181	Piston Ring T04B C/E +.010" Pink
3525568	1152302124	Bearing H2B/C/D O/D +.010"/ID Std
3525569	1152302120	Bearing H2B/C/D O/D Std/ID -.010"
3525570	1152302120	Bearing H2B/C/D O/D +.010"/ID -.010"
3525739	1152301320	Thrust Bearing (H1C)
3526275	1100180100	Bearing OD. Std / ID Std. T12 / T18
3526277	1100180320	Thrust Washer T12
3526281	1100180150	O RING
3526287	1100045170	Piston Ring TA45/ TA51/T18 /T 12 /T 6 C/E
3526288	1100045160	Piston Ring Step Bore(T12/45/51/TV)
3526291	1100180160	Piston Ring T18 S/B
3526293	1100120550	Lock plate (Insert Plate) T12
3526294	1100180550	Lock Plate T18
3526295	1100120520	Lock plate, Turb. Side. TE06 / T12

3526298	1101461550	Lock Plate TV series
3526299	1100120480	Clamp plate, Turb. Side T12
3526303	1100120610	Bolt. (Insert Plate) T12
3526304	1100120600	Bolt. Turb. Side TE06 / T12
3526314	1100120350	Shaft Nut. T12
3526316	1250040350	Shaft nut (4LE/F/GK)
3526318	1100180140	Snap Ring.
3526673	1100040124	Bearing TO4B OD +.010"/Std ID (Bronze NO Tin plating)
3526675	1100040120	Bearing +.010" OD / -.010" ID (Bronze. NO Plating)
3527039	1250040127	Bearing 4L Std OD/-.010"ID
3527184	1100030561	Bolt H1C Metric (Seal Plate to B/Hsg) Micro encapsulated
3529158	1100040320	THRUST BEARING
3529372	1100120645	Nut. V Band clamp. T12
3529812	1100040400	Comp.Wheel (TO4B)
3536320	1100180190	Wear Washer (Bearing) T12
3545039	1301504750	Service Kit 4LE/4LF
3545115	1100030270	Carbon Seal T3/T04B
3545121	1100025150	O Ring (Insert / Seal Plate T2 / T25
3545123	1100025620	Screw Thrust Brg Ret. T2/T25 (Micro Encapsulated)
3545126	1100020100	Bearing Std. (Short T2/T25)Bronze
3545127	1100025100	Bearing Std. (Long T2/T25
3545132	1100180221	Spacer Sleeve (T18)
3545133	1100180220	THRUST SPACER T18A/TV71-81
3545136	1100180110	Bearing T12/T18 +.005"OD/-.005"ID Bronze NO Plateing
3545162	1100180120	Bearing T12/T18 +.010"OD/-.010"ID Bronze NO Plateing
3545163	1100180127	Bearing T18 Std OD/ -.010" ID
3545164	1100120160	Piston Ring Smooth Bore T12
3545171	1100040200	Thrust Collar (Dynamic TO4B)
3545299	1250403321	Thrust Bearing 3LM
3545333	1101061200	Thrust Collar (TV61-81 T18A)
3545338	1152301120	Bearing HC1 +.010" OD / -.010" ID
3545339	1152301124	Bearing HC1 +.010" OD / Std ID
3545341	1100120150	O Ring. Seal Plate T12
3545342	1100120155	O Ring B/Housing to C/Hsg T12
3545355	1301027480	Clamp Plate (K27/3LKZ Turb)
3545357	1250030150	O Ring (Insert HSKM)
3545358	1301027500	Clamp Plate (3LD/3LEP/K27 Comp.)
3545361	1301027160	Piston Ring K26 Turb. & Comp.
3545370	1301026620	Cap screws K26/27/ S/P to B/Hsg
3545371	1301027581	Washer (K27 Seal Plate)
3545372	1301027101	Bearing (Grooved O.D. K27)
3545373	1301027150	O Ring (K27 Comp. Hsg.)
3545374	1301027320	Thrust Bearing (K27)
3545375	1301027100	Bearing (Smooth O.D. K27)
3545377	1100180124	Bearing T18 +.010" OD/Std ID
3545403	1250404717	Core Assy 4MD-454
3545419	1301027310	Oil Deflector (K26/K27)
354542	1301027350	Shaft Nut (K24/26/27) M6x6 SW12 (5326-128-0200)
3545420	1401405320	Thrust Bearing TDO5
3545421	1301027350	Shaft Nut (K24/26/27)
3545546	1401405150	O Ring TDO5/TDO6 (Insert Plate)
3545552	1401405160	Piston Ring TC05 / 6 T/E
3545553	1401405170	Piston Ring TCO5/6 TD05/6 comp end
3545651	1152301751	Repair Kit (Full) H1B
3545658	1150403750	Repair Kit 3LD
3545659	1301504750	Service Kit 4LE/4LF
3545664	1152203750	Repair Kit (H3B)
3545824	1101280750	Repair Kit TV6/7/8
3545832	1100180751	Repair Kit T18 (Step Bore)
3545838	1100120752	Service Kit T12 (Minor) Step Bore
3545839	1100120753	Service Kit T12 (minor) Smooth Bore
3545989	1100040200	Thrust Collar (Dynamic TO4B)
3819900	1900000035	GASKET
57749	1250404860	T/Hsg 6Hole out M8-6H
50503	1250404712	Core Assy 4MD-354

50513	1250404713	Core Assy 4MD-759
50518	1250404700	Core Assy 4MD-759
50846	1150403700	Core Assy Holset 3LD-9 Smooth Bore B/hsg tapped UNC & Ford
51135	1250403300	Insert Plate
51136	1250403320	Thrust Bearing 3LD
51140	1250403100	Bearing 3LD (Std)
51142	1250403310	Oil Deflector 3LD
51143	1250403645	V Clamp
51145	1250403561	Bolt
51171	1250404408	C/W 4MD-659
51197	1301027500	Clamp Washer 3LD C/Hsg (replace 2 with 1x 1301027500)
5220-109-0201	1200050630	Washer (2 Piece clamp Plate)
51217	1250403426	Comp Wheel 279 / 3LD
51220	1250403425	C/Wheel 259 / 3LD9
51240	1301036240	THRUST RING
51264?	1250404860	T/Hsg 6Hole out M8-6H
51301	1250404413	C/W 4MD759
51307	1250404320	Thrust Bearing 4MD
51343?	1250404861	T/Hsg 6Hole out UNC
51375	1250404350	Shaft Nut 4MD
51382	1250504401	Comp Wheel 4LE 504 Radial
51543	1150403450	Bearing Hsg. 3LD Ford use 1150403450
51625	1250403100	Bearing 3LD (Std)
51710	1250403450	Bearing Housing 3LD (step bore)
51749	1250404451	B/Hsg Oil inlet and outlet M8-6H
51773	1250403200	Flinger 3LD
51916	1250403100	Bearing 3LD (Std)
51948	1250030150	O Ring (Insert HSKM)
52163	1250404451	B/Hsg Oil inlet and outlet M8-6H
52187	1250403800	Comp Cover 259 / 3LD9
52195	1150400160	Piston Ring (HCSKM) Stainless
52408	1250404903	Noz Ring 4MD (.280)
52409	1250404902	Noz Ring 4MD (.307)
52417	1250403861	Turbine Housing 3LD Twin Entry- 6 bolt discharge- 5/16 x18UNC 2.24sq in
52441	1250030150	O Ring (Insert HSKM)
52700	1250404435	Shaft and Wheel 4MD
52786	1100120350	Shaft Nut. T12
52799	1250040155	O Ring (4LE/F/GK) C/Hsg to B/Hsg
52869	1250040320	Thrust Bearing (4L-/HC3/3LKS)
52951	1150400170	Piston Ring Stiff Ring
52963	1150403452	Bearing Housing 3LD (Smooth bore - metric)
52980	1250404150	O Ring 4MD
52981	1250404155	O Ring C/End 4MD
52987	1150504200	Flinger Sleeve 4LE 2 ring groove (MELETTx 2 parts)
52988	1150403435	Shaft & Wheel 3LD (2x Piston Ring Grooves)
52989	1250403200	Flinger 3LD
53281	1150403750	Repair Kit 3LD
53282	1150403450	Bearing Hsg. 3LD UNC Thread use 1150403450
53368	1150403753	Repair kit 3LD (Step bore,Inc. Gaskets)
53374	1250403700	Core Assy. 3LD-9 /3LD-259
53414	1150403700	Core Assy Holset 3LD-9 Smooth Bore B/hsg tapped UNC
53424	1250404701	Core Assy 4MD-458
53440	1250404702	Core Assy 4MD-757
53445	1150403701	Core Assy. 3LD-1
53472	1301504750	Service Kit 4LE/4LF
53473	1150403700	Core Assy Holset 3LD-9 Smooth Bore B/hsg tapped UNC
53474	1150403750	Repair Kit 3LD
53573	1150403701	Core Assy Holset 3LD-1 Smooth Bore B/hsg tapped UNC & Ford
53632	1250404714	Core Assy 4MD-458
53634	1250404715	Core Assy 4MD-757
53658	1150403701	Core Assy Holset 3LD-1 Smooth Bore B/hsg tapped UNC & Ford
53839	1150403701	Core Assy Holset 3LD-1 Smooth Bore B/hsg tapped UNC & Ford
54134	1150403704	Core Assy. 3LD-1
54149	1150403750	Repair Kit 3LD
54451	1150403750	Repair Kit 3LD

54763	1250403700	Core Assy. 3LD-9 /3LD-259
54972	1150403750	Repair Kit 3LD
55310	1150403750	Repair Kit 3LD
55739	1900000037	Gasket (Oil Inlet) T04B / H2C
55766	1250404200	Flinger Sleeve
55791	1250403435	Shaft / Wheel (1 groove)
55920	1250404435	Shaft and Wheel 4MD
56096	1250403802	Comp Cover 279 / 3LD1
56438	1150513300	Insert Plate 3FJ/3LM
56583	1150403800	Comp Cover 279 / 3LD1
56754	1152302160	Piston Ring (H1C/H2C/3FD/J) Turb.End
57175	1152303436	Shaft & Wheel (HC3 UNF T2)
57736	1250040320	Thrust Bearing (4L-/HC3/3LKS)
57753	1250040260	Oil Control Sleeve (4LE)
57955	1250040400	Comp Wheel 4LE 302 Radial
58226	1250403450	Bearing Housing 3LD (step bore)
58656	1250040350	Shaft nut (4LE/F/GK)
58848	1152302170	Piston Ring (H1C-H2C) Comp End
58963	1150413100	Bearing 3FD/FJ ODStd/IDStd
59513	1250040320	Thrust Bearing (4MF) Taper land ssb 3519318
59517	1301036240	THRUST RING 4MF (Use 1301036240)
59526	1301027610	Bolt (K27/K33/H2C/Garrett S/P to C/Hsg)
59618	1150704300	Insert Plate 4LGK/HC3
59917	1301027600	Bolt (K27/T3 Turbine HT)
60329	1250403320	Thrust Bearing 3LD With Angle hole for oil can use 1250403320
61255	1250403240	Thrust Ring 3LD
61275	1250403240	Thrust Ring 3LD
61685	1152303435	Shaft & Wheel (HC3/K361) UNF T3
61697	1152302100	Bearing Std OD/ Std ID H2B/C/D
61844	1150400170	Piston Ring
61867	1150400170	Piston Ring
62259	1100040140	Snap Ring (thin)
62915	1152302150	O Ring (H2A-B-C Seal plate) V75 67.95 2.62 B
9510	1301036140	Snap Ring (H.S.K)
9511	1250404435	Shaft and Wheel 4MD
9516	1150400170	Piston Ring
9516	1150400172	Piston Ring
9517	1100040180	Piston Ring T04B T/end
9523	1250404142	Snap Ring
9627?	1250404401	Compressor Wheel 4MD-351 (Hol 4B)
9737	1900000035	GASKET
9738	1900000025	GASKET
9749	1900000003	GASKET
9753	1152302140	SNAP RING H2C / 3LKS
9764	1150413160	Piston Ring Comp.Turb. End 3FJ
9765	1152303170	Piston Ring
9774	1152302520	Lock Plate (H2C Turb)
9779	1301027580	Spring Washer (Comp. Hsg. Retainer) 3LD/4LG 1/4"
9867	1150400172	Piston Ring As 9816 but sintered
9988	1900000025	GASKET



CATERPILLAR - MELETT Cross Reference

To quickly find a part, use the ctrl+F option. If the part you require is not found, please contact Melett direct with you enquiry.

Melett Ltd

Tel: +44 (0)1924 488686

Fax: +44 (0)1924 459200

Email: sales@melett.com

Melett 2002. All manufacturers names, numbers, symbols and descriptions used herein are for reference purposes only and do not imply that any part listed is the product of these manufacturers.


CAT Part No.	MELETT PART No	DESCRIPTION
	1900000003	Gasket. Turb. Inlet Twin Entry T12
	1100180190	Wear Washer (Bearing) T12 / T18
0R5386	1250404435	Shaft and Wheel 4MD (CAT Reman No.)
0R5400	1250404450	B/Hsg Oil inlet and outlet UNC without threaded mtg bosses on side (CAT Reman No.)
1C0569	1100040560	Bolt
1N3505	1100180222	Spacer Sleeve
1N3806	1152302160	Piston Ring Turb.End
1N3999	1101081702	C.H.R.A TV/TW8106
1P0715	1301027500	Clamp Plate (Comp.)
1P0718	1100120350	Shaft Nut. T12
1P0725	1152302160	Piston Ring (Turb.End)
1P1111	1100040320	Thrust Bearing
1P1112	1100040480	Clamp Plate (Turb.End)
1P1113	1100040520	Lock Plate (TO4B Turb.)
1P1114	1100040100	Bearing (T3/TO4B) Standard
1P1115	1100040160	Piston Ring TO4B(Step.Turb)
1P1120	1100040150	O Ring (B/Hsg TO4B)
1P1123	1100040200	Thrust Collar (Dynamic TO4B)
1P1124	1100040170	Piston Ring Comp T04B
1P1125	1100040350	Shaft Nut (TO4B T3 RHT)
1P1136	1100180195	Pin (B/Hsg) Roll Pin
1P1161	1100120402	Comp. Wheel TE06 / T1227
1P1162	1100120702	Core Assy T1227
1P4983	1100180700	C.H.R.A. T1810,18
1P5467	1250404100	Bearing 4B-D-V4HD-4MD Std OD/ Std ID With grooved ends & Grooved inside Dia
1P715	1301027500	Clamp Plate (Comp.)
1P9918	1100180160	Piston Ring T18 S/B
1P9961	1100120702	Core Assy T1227
1S0772	1150400160	Piston Ring (HCSKM)
1S1617	1100180610	Bolt (Comp end)
1S1770	1100180350	Shaft Nut Nut
1S2098	1250404340	Heat Shield
1S2501	1250404718	Core Assy. 4MD-754
1S2504	1100180700	C.H.R.A. T1810,18
1S3169	1250404150	O Ring 4MD
1S3887	1250404260	Oil Control Sleeve 4B, 4MD, 4HD
1S4295	1900000003	GASKET
1S4810	1900000025	Gasket. Oil Outlet T12
1S5372	1250404450	B/Hsg Oil inlet and outlet UNC without threaded mtg bosses on side
1S6595	1900000035	Gasket. Oil Inlet T12
1S7390	1100180155	O Ring T18
1S9169	1100180600	Bolt Turbine
1S9172	1100180520	LOCKPLATE TURB
1S9179	1100180600	Bolt Turbine
1W0445	1100120705	CHRA T1226
1W1653	1101081708	C.H.R.A. TV/TW8113/14
1W4462	1100045320	Thrust Bearing TA45/TA51
1W4464	1100045220	Spacer Sleeve (T45)

1W6809	1101081708	C.H.R.A. TV/TW8113/14
2A0762	1250403561	Bolt
2L0625	1100180610	Bolt (Comp end)
2M2567	1250404140	Snap Ring
2M2571	1100300200	Thrust Collar (T30)
2P3158	1100180160	Piston Ring T18 S/B
2P936	1152302140	SNAP RING H2C / 3LKS
2P9607	1100040140	Snap Ring (thin)
2S1185	1250404240	Thrust Ring
2S1186	1250404320	Thrust Bearing 4MD
2S1302	1250404411	C/W 4MD-755 also 4HD
2S1304	1250404346	V Band Clamp Assy Comp/Hsg 9"
2S1305	1250404300	Insert Plate 4MD 4HD
2S1306	1250404320	Thrust Bearing 4MD
2S1307	1250404141	Snap Ring 4HD
2S1308	1250404310	Oil Deflector 4MD
2S1310	1250404330	Spacer Plate
2S3294	1100180221	Spacer Sleeve (T18)
2W0715	1101280750	Repair Kit TV6/7/8
2W0716	1100040750	Service Kit TO4B ss 6N7236
2W0719	1100120753	Service Kit T12 (minor) Smooth Bore
2W0720	1100180752	Cartridge Repair Kit T18
2W4130	1101670360	BACKPLATE TV7201
2W6734	1101481700	CHRA TL8106
2W725	1301504750	Service Kit 4LE/4LF
3B4504	1250403561	Bolt
3S1416	1100180700	C.H.R.A. T1810,18
3S1422	1100180401	COMPR WHEEL T1810
3S1423	1100180435	SHAFT & WHEEL
3S1427	1250404150	O Ring 4MD
3S1503	1250404712	Core assy 4MD-354 (CAT Reman)
3S1505	1250404717	Core Assy 4MD-454 (CAT Reman No.)
3S1507	1250404718	Core Assy. 4MD-754 (CAT Reman No.)
3S2346	1100180400	Comp. Wheel T1817
3S2978	1100180700	C.H.R.A. T1810,18
3S3998	1250404400	Compressor Wheel 4MD-351
3S4007	1250404712	Core Assy 4MD-354
3S4008	1250404717	Core Assy 4MD-454
3S4009	1250404716	Core Assy. 4MD-351
3S4226	1250404718	Core Assy. 4MD-754
3S4480	1100120450	Bearing Housing T12
3S4481	1100120400	Comp. Wheel TE06 / T1210
3S4482	1100180201	Thrust Collar (T18)
3S4483	1100120221	Spacer Sleeve (T12) ssb 1100060200
3S4484	1100120350	Shaft Nut. T12
3S4486	1100120300	THRUST PLATE ASSY
3S4487	1100120550	Lock plate (Insert Plate) T12
3S4488	1100120610	Bolt. (Insert Plate) T12
3S4489	1100120150	O RING
3S4490	1100120340	SHROUD
3S5126	1100120600	Bolt. Turb. Side TE06 / T12
3S5127	1100120480	Clamp plate, Turb. Side T12
3S5128	1100120520	Lock plate, Turb. Side. TE06 / T12
3S5129	1100120345	Clamp. V Band. T12
3S5130	1100120600	Bolt. Turb. Side TE06 / T12
3S5135	1100120155	O Ring B/Housing to C/Hsg T12
3S5441	1250404450	B/Hsg Oil inlet and outlet UNC without threaded mtg bosses on side
3S5853	1250404100	Bearing 4B-D-V4HD-4MD Std OD/ Std ID With grooved ends & Grooved inside Dia
3S5854	1250404100	OD/ Std ID With grooved ends & Grooved inside Dia
3S7577	1100120700	Core Assy T1210
3S8281	1250404408	C/W 4MD-659
3S9223	1250040320	Thrust Bearing (4L-/HC3/3LKS)
4M6646	1100180195	Pin (B/Hsg) Roll Pin (For solid pin use 400705.0000)
4M6983	1301036140	Snap Ring (H.S.K)
4M6989	1100040180	Piston Ring T04B T/end
4M6990	1250404142	Snap Ring
4M8012	1250404350	Shaft Nut 4MD
4M8013	1150400170	Piston Ring Stiff Ring

4N5647	1100180700	C.H.R.A. T1810,18
4N5652	1100180160	Piston Ring T18 S/B
4N6861	1100040400	Comp.Wheel (TO4B)
4N6863	1100040360	Seal Plate T04B Dynamic
4N6864	1100040500	Clamp Plate (TO4B Comp.)
4N6865	1100040540	Lock Plate (TO4B Comp.)
4N7595	1150400160	Piston Ring (HCSKM)
4N7597	1250040320	Thrust Bearing (4L-/HC3/3LKS)
4N7600	1250040350	Shaft nut (4LE/F/GK)
4N7609	1301036240	THRUST RING
4N9683	1250404350	Shaft Nut 4MD (Nylock)
4S5384	1100120700	Core Assy T1210
4S5794	1100180435	SHAFT & WHEEL
4S6479	1100120300	THRUST PLATE ASSY
4S9248	1150400172	Piston Ring Stainless Red
4S9701	1100120435	Shaft & Wheel T12
4S9702	1100120450	Bearing Housing T12
4S9703	1100120700	Core Assy T1210
4S9710	1100120160	Piston Ring
4S9736	1100180201	Thrust collar TE06 / T12 Use with 1100120221
4W7344	1252419100	Bearing S4 Range ss (199910 Brg +199909 Washer)
5M3034	1100120350	Shaft Nut. T12
5M3038	1100180150	O RING
5M3062	1100180600	Bolt Turbine
5M9670	1100040140	Snap Ring (thin)
5P5756	1100120150	O Ring. Seal Plate T12
5P5757	1250030150	O RING
5S0498	1100120700	Core Assy T1210
5S2866	1100180435	SHAFT & WHEEL
5S2867	1100180160	Piston Ring T18 S/B
5S2884	1100180202	Thrust Collar (T18)
5S4546	1250403140	Snap Ring
5S4547	1301036220	Spacer Sleeve (4LE/K36)
5S4548	1250030150	O Ring (Insert HSKM)
5S4550	1301036240	THRUST RING
5S4551	1250040260	Oil Control Sleeve (4LE)
5S4552	1250040320	Thrust Bearing (4L-/HC3/3LKS)
5S4554	1250040155	O Ring (4LE/F/GK) C/Hsg to B/Hsg
5S4555	1250040350	Shaft nut (4LE/F/GK)
5S4556	1250403300	Insert Plate
5S6773	1100180340	Turbine Back Plate T18
6N1526	1150413160	Piston Ring 3LD/3LDA/3LM/S3A
6N1527	1150513300	Insert Plate 3FJ/3LM
6N1528	1250403321	Thrust Bearing 3LM
6N3250	1100120404	Comp. Wheel T1237
6N4606	1101081436	S/W TV8108
6N5002	1100180221	Spacer Sleeve (T18)
6N5004	1100180320	Thrust Washer T12
6N6507	1100120703	Core Assy T1237
6N6516	1100120706	C.H.R.A T1231/2
6N6518	1101081702	C.H.R.A TV/TW8106
6N6525	1250404716	Core Assy. 4MD-351 (CAT Reman)
6N6607	1100120703	Core Assy T1237
6N7200	1100120405	Comp. Wheel T1238
6N7202	1100120704	Core Assy T1238
6N7236	1100040750	Service Kit TO4B ssb 2W0716
6N7239	1100120753	Service Kit T12 (minor) Smooth Bore
6N7461	1250504401	Comp Wheel 4LE 504 Radial
6N7960	1101081703	C.H.R.A. TV/TW8106
6N7961	1101881401	Comp. Wheel TW8106
6N7962	1101680360	PLATE ASSY TV81
6N7966	1101081704	C.H.R.A TV/TW8107
6N7967	1101881400	Comp. Wheel TV8107
6N8653	1100120704	Core Assy T1238 (CAT Reman)
6N8654	1101081703	C.H.R.A. TV/TW8106 (CAT reman)
6N9783	1250404350	Shaft Nut 4MD
6V2751	1100120600	Bolt. Turb. Side TE06 / T12
7C2243	1252419124	Bearing S4A/D +.010" OD / Std OD

7C2245	1252419120	Bearing S4 +.010" OD / -.010" OD
7C3824	1101072700	Core Assy TW7204
7M7246	1100180520	LOCKPLATE TURB
7M7611	1250404140	Snap Ring
7M7612	1250404260	Oil Control Sleeve 4B, 4MD, 4HD
7M7613	1250404100	Bearing Std OD/ Std ID, bearing group ssb 3S5854
7M9831	1100120610	Bolt. (Insert Plate) T12
7M9885	1100045170	Piston Ring TA45/ TA51/T18 /T 12 /T 6 C/E
7M9886	1100180550	Lock Plate T18
7M9888	1100180550	Lock Plate T18
7M9907	1250404240	Thrust Ring
7M9908	1250404200	Flinger Sleeve
7M9910	1100120610	Bolt. (Insert Plate) T12
7M9912	1250404340	Heat Shield
7M9916	1250404346	V Band Clamp Assy Comp/Hsg 9"
7M9918	1100120645	Nut. V Band clamp. T12
7M9919	1250404630	Spring Washer, lock tab, Thrust bearing
7M9923	1250404220	Spacer Sleeve
7N239	1250040350	Shaft nut (4LE/F/GK)
7N2856	1150400160	Piston Ring (HCSKM)
7N3191	1100040117	Bearing Std OD/ .005" ID
7N3192	1100040127	Bearing T3/T04B OD std/ ID -.010"
7N3759	1100045160	Piston Ring (Step Bore) T12
7N3760	1100120340	Heat Shield T12
7N3762	1250404320	Thrust Bearing 4MD
7N456	1100120350	Shaft Nut. T12
7N6606	1100120160	Piston Ring Smooth Bore T12
7N6607	1100180161	Piston Ring T18 Smooth Bore
7N6608	1100180160	Piston Ring T18 S/B
7N6609	1100040160	Piston Ring TO4B(Step.Turb)
7N7248	1100120701	Core Assy T1224
7N7249	1100120705	Core Assy T1226
7N7250	1100120700	Core Assy T1210
7N7251	1100120702	Core Assy T1227
7N7252	1100120450	Bearing Housing T12
7N8188	1101481450	Bearing Hsg.Water Cooled TL81
7S5854	1100180700	C.H.R.A. T1810,18
7S7697	1250504401	Comp Wheel 4LE 504 Radial
8M5677	1250403561	Bolt
8M7167	1250404250	Shim 0.003
8M7168	1250404251	Shim 0.005"
8M7169	1250404252	Shim 0.010"
8M7946	1250404901	Noz Ring 4MD (.246)
8M7948	1250404900	Noz Ring 4MD (.318)
8M8917	1100180100	Bearing OD. Std / ID Std. T12 / T18
8M9886	1100180550	Lock Plate T18
8N4153	1100040114	Bearing OD +.005"/Std ID
8N4154	1100040124	Bearing TO4B OD +.010"/Std ID
8N4155	1100040110	Bearing +.005"OD/-.005"ID
8N4156	1100040120	Bearing +.010" OD / -.010" ID
8N6553	1101481700	CHRA TL8106
8S1341	1100180435	SHAFT & WHEEL
8S2738	1250404320	Thrust Bearing 4MD
8S5167	1100120436	Shaft & Wheel T12
8S5168	1100120401	Comp. Wheel T1224
8S5169	1100120300	Thrust plate Assy. T12
8S6060	1100120700	Core Assy T1210 (CAT Reman No.)
8S6832	1100120701	C.H.R.A. T1224
8S6833	1100120701	Core Assy T1224 Cat Rebuild No. for 7N7248
8S7692	1100180700	C.H.R.A. T1810,18
8S8041	1100120701	C.H.R.A. T1224
8S8042	1100180200	Thrust collar T12
8S8043	1100120220	Thrust Spacer (T12) ssb 1100060200
8S9222	1150504200	Flinger Sleeve 4LE 2 ring groove (MELETTx 2 parts)
8S9223	1250040320	Thrust Bearing (4L-/HC3/3LKS)
9L6239	1100120706	Core Assy T1231
9L6242	1100120403	Comp. Wheel T1233
9L6243	1100120455	Bearing Housing T12

9L6245	1100045160	Piston Ring Step Bore(T12/45/51/TV)
9M0491	1250404435	Shaft and Wheel 4MD
9M0493	1250404404	Compressor Wheel 4MD-454
9M0496	1250404402	Compressor Wheel 4MD-354
9M497	1250404409	C/W 4MD-754
9M500?	1250404435	Shaft and Wheel 4MD
9M8911	1101061200	Thrust Collar (TV61-81 T18A)ssb1101061200
9M8912	1100180221	Spacer Sleeve (T18)
9M8913	1100180350	Shaft Nut Nut
9M8915	1100180140	Snap Ring.
9M8916	1100180100	Bearing OD. Std / ID Std. T12 / T18
9M8917	1100180320	Thrust Washer T12
9M8918	1100180300	Thrust Plate (T18)
9M8919	1100045170	Piston Ring TA45/ TA51/T18 /T 12 /T 6 C/E
9M8924	1100180500	CLAMP PLATE
9M9545	1250404155	O Ring C/End 4MD/4HD
9M9914	1250404310	Oil Deflector 4MD
9M9934	1250404300	Insert Plate 4MD 4HD
9N2031	1101081702	C.H.R.A TV/TW8106
9N2035	1101672450	Bearing Housing TV61/71/81
9N2036	1101461550	Lock Plate TV series
9N2037	1101680340	Heat Shield, (Cast)
9N2038	1101068345	CLAMP TURB TV61
9N2039	1101680346	CLAMP CMP TV81
9N2041	1100180775	Bearing Kit T18 (2 Brgs & 2 Washers)
9N2043	1101081435	SHFT & WHL TV81
9N2045	1101680361	SEAL PLATE
9N2046	1100180220	THRUST SPACER T18A/TV71-81
9N2378	1250040400	Comp Wheel 4LE 302 Radial
9N2640	1101081705	CHRA TV/TW8108
9N3600	1101081705	CHRA TV/TW8108
9N3674	1101081403	C/W TV8108
9N3676	1101081707	C.H.R.A TV/TW8112
9N3701	1101680340	Heat Shield, (Cast)
9N5263	1101081706	CHRA TV/TW8110
9S2610	1100120702	Core Assy T1227
9S4845	1100180221	Spacer Sleeve (T18)
9S6207	1100120402	COMPR. WHEEL T1227
9S7545	1100180100	Bearing OD. Std / ID Std. T12 / T18
9S8000	1100180340	Turbine Back Plate T18
9S8011	1100180161	Piston Ring T18 Smooth Bore
9S8012	1100120160	Piston Ring
9S9327	1100120340	SHROUD
OR5364	1100180300	Thrust Plate (T18) (CAT Reman)
OR5393	1101081436	S/W TV8108 (CAT Reman)
OR5395	1101081435	SHFT & WHL TV81(CAT Reman)
OR5396	1100120436	Shaft & Wheel T12 (CAT reman)
OR5397	1100180435	Shaft & Wheel (Cat Reman)



CUMMINS - MELETT Cross Reference

To quickly find a part, use the ctrl+F option. If the part you require is not found, please contact Melett direct with you enquiry.

Melett Ltd

Tel: +44 (0)1924 488686

Fax: +44 (0)1924 459200

Email: sales@melett.com

Melett 2002. All manufacturers names, numbers, symbols and descriptions used herein are for reference purposes only and do not imply that any part listed is the product of these manufacturers.

CUMMINS Part No.	MELETT PART No	DESCRIPTION
	1200050182	Piston Ring (Turb) +0.010 OD/-0.025" Width
	1200050127	Bearing T50 Std OD / -0.010"ID
114753	1900000002	GASKET
115156	1200050160	Piston Ring (Turb) CummST/VT50
156420	1200050100	Bearing (Cummins ST/ VT 50)
156444	1200050170	Piston Ring (Comp) CummST/VT50
167299	1200050640	Lock Nut(2 piece clamp plate)
170510	1200050281	Fiber Insert (Cummins ST/VT50)
171570	1200050340	Heat Shield (T50-ST50-VT50)
190849	1900000001	Gasket (Turb. 4 bolt) ST/VT50
194010	1200050600	Bolt (2 piece Clamp) ST/VT50
195840	1200050160	Piston Ring (Turb) CummST/VT50use1200050160
199415	1200050155	O Ring (B/Hsg) Cummins ST/VT50
201048	1900000025	Gasket. Oil Outlet T12
201049	1900000035	Gasket. Oil Inlet T12
202376	1200050450	Bearing Housing (T50-ST50-VT50)use1200050450
202377	1200050280	Heat Packing (Cummins ST/VT50)
202392	1200050450	Bearing Housing (T50-ST50-VT50)
202456	1200050150	O Ring (Seal Plate)Cum ST/VT50
202457	1200050155	O Ring (B/Hsg) Cummins ST/VT50
202853	1100180140	Snap Ring.
202854	1100180100	Bearing OD. Std / ID Std. T12 / T18
202855	1100180190	Wear Washer (Bearing) T12 / T18
202856	1100180320	Thrust Washer T12
202857	1101083200	Thrust Collar (T18A - TV83)
202858	1100180220	THRUST SPACER T18A/TV71-81
202859	1100181150	O RING
202860	1100045170	Piston Ring TA45/ TA51/T18 /T 12 /T 6 C/E
202862	1100181550	Lock Tab (Back Plate)
202865	1100180350	Shaft Nut Nut
202870	1100040560	BOLT
202873	1900000003	GASKET
205396	1900000003	Use 1900000003 Metal Twin Entry
207425	1100180100	Bearing OD. Std / ID Std. T12 / T18
207426	1100180220	THRUST SPACER T18A/TV71-81
207431	1100180160	Piston Ring T18 S/B
207432	1100120645	Nut. V Band clamp. T12
211375	1200050156	O Ring C/Hsg (Cumm ST/VT50)
213806	1200050435	Shaft & Wheel (T50) ssb 1200050436
214086	1200050436	Shaft & Wheel (T50)

216791	1200050426	Comp. Wheel (T46-T50-ST50-VT50)
216793	1200050429	C/Wheel T50 / ST50
216794	1200050425	Comp. Wheel (T46-T50-ST50-VT50)
216795	1200050427	Comp. Wheel (T46-T50-ST50-VT50)
216797	1200050426	Comp. Wheel (T46-T50-ST50-VT50)
216799	1200050429	C/Wheel T50 / ST50
216801	1200050425	Comp. Wheel (T46-T50-ST50-VT50)
216802	1200050200	SPACER, THRUST
216804	1200050300	Insert Seal Plate (S/Back) T50
216805	1200050300	Insert Seal Plate (S/Back) T50
3002731	1200050428	Comp. Wheel (T46-T50-ST50-VT50)
3003835	1200050750	Service Kit T-ST-VT 50 Cum Lrg
3005327	1200050700	Core Assy ST50/VT50
3007755	1200046425	Comp Wheel (T46 / T46B)
3009197	1100180222	Spacer Sleeve
3009198	1101083200	Thrust Collar (T18A - TV83)
3010257	1200050700	Core Assy ST50/VT50
3012993	1200046426	Comp Wheel (T46 / T46B)
3022969	1200050160	Piston Ring (Turb) CummST/VT50
3023555	1200050751	Service Kit T-ST-VT 50 Cum Sml
3025390	1200050436	Shaft & Wheel (T50)
3026034	1200046450	Bearing Housing (CumminsT46B)
3029512	1200046427	Comp Wheel (T46 / T46B)
3031980	1200046427	Comp Wheel (T46 / T46B)
3034304	1200050350	Shaft Nut (Cummins ST/ VT 50 T46)
3034720	1200050345	COUPLING, V-BAND
3034736	1200050160	Piston Ring (Turb) CummST/VT50
3038745	1200050450	Bearing Housing (T50-ST50-VT50)
3500681	1900000037	Gasket Oil Inlet H2C
3500682	1900000025	GASKET
3500683	1900000003	GASKET
3500684	1152303170	PISTON RING .750"
3500686	1100120645	Nut. V Band clamp. T12
3500688	1250404142	Snap Ring
3500689	1301036220	Spacer Sleeve (4LE/K36)
3500691	1250040350	Shaft nut (4LE/F/GK)
3500692	1250040100	Bearing (4LE- HC3 -HT3B -K361) Std OD/ Std ID
3500693	1150400160	Piston Ring (HCSKM)
3500694	1250040260	Oil Control Sleeve (4LE)
3500695	1250403140	Snap Ring
3500698	1200050630	WASHER
3500699	1200050630	WASHER
3500700	1301036240	THRUST RING
3500703	1250030150	O Ring (Insert HSKM)
3500705	1250040320	Thrust Bearing (4L-/HC3/3LKS)
3500710	1150704300	Insert Plate 4LGK/HC3
3503100c	1152301100	Bearing Std (H1C)
3503335	1100120645	Nut. V Band clamp. T12
3503707	1152302320	Thrust Bearing H2C
3504413c	1152302100	Bearing Std OD/ Std ID H2B/C/D
3519471	1250040350	Shaft nut (4LE/F/GK)
3521441c	1150400160	Piston Ring (HCSKM)
3521442	1152303170	Piston Ring
3709510	1301036140	Snap Ring (H.S.K)
3709737	1900000037	Gasket Oil Inlet H2C
3709738	1900000025	GASKET
3709753	1152302140	SNAP RING H2C / 3LKS
3709765	1152303170	PISTON RING .750"
3709774	1152302520	LOCKPLATE (T)
3715186	1100120645	Nut. V Band clamp. T12

3718373	1250404142	Snap Ring
3718455	1301036220	Spacer Sleeve (4LE/K36)
3722366	1250040100	Bearing (4LE- HC3 -HT3B -K361) Std OD/ Std ID
3722447	1150400160	Piston Ring (HCSKM)
3723863	1250403140	Snap Ring
3751145	1250403561	Bolt
3751240	1301036240	THRUST RING
3751948	1250030150	O Ring (Insert HSKM)
3752869	1250040320	Thrust Bearing (4L-/HC3/3LKS)
3755739	1900000037	Gasket Oil Inlet H2C
3756754	1152302160	Piston Ring (H1C/H2C/3FD/J) Turb.End
3757736	1250040320	Thrust Bearing (4L-/HC3/3LKS)
3757753	1250040260	Oil Control Sleeve (4LE)
3758656	1250040350	Shaft nut (4LE/F/GK)
3758848	1401404180	Piston Ring TD04 T/end +.010"OD
3758848	1152302170	Piston Ring (H1C-H2C) Comp End
3759618	1150704300	Insert Plate 4LGK/HC3
3761697	1152302100	Bearing Std OD/ Std ID H2B/C/D
3762915	1152302150	O'RING INSERT H2C
3801096	1200050751	Service Kit T-ST-VT 50 Cum Sml
3801101	1200050752	Service Kit T-ST-VT 50 Cum MajorKit (Inc. B/Hsg)
3904761	1152301100	Bearing Std (H1C)
70502	1301036140	Snap Ring (H.S.K)
AR06665	1200050435	Shaft & Wheel (T50) ssb 1200050436
AR07936	1200050751	Service Kit T-ST-VT 50 Cum Sml
AR10058	1200050435	Shaft & Wheel (T50) ssb 1200050436
AR10059	1200050436	Shaft & Wheel (T50)
AR10204	1200050436	Shaft & Wheel (T50)
AR12894	1200050700	Core Assy ST50/VT50
S-107	1100180610	Bolt (Comp end)
S-114	1250403561	Bolt
S-118-A	1250403561	Bolt
S-156-B	1200050600	Bolt (2 piece Clamp) ST/VT50
S-222-A	1200050350	Shaft Nut (Cummins ST/ VT 50
S-631	1200050630	Washer (2 Piece clamp Plate)



IHI - MELETT Cross Reference

To quickly find a part, use the ctrl+F option. If the part you require is not found, please contact Melett direct with you enquiry.

Melett Ltd

Tel: +44 (0)1924 488686

Fax: +44 (0)1924 459200

Email: sales@melett.com

Melett 2002. All manufacturers names, numbers, symbols and descriptions used herein are for reference purposes only and do not imply that any part listed is the product of these manufacturers.

IHI Part No.	MELETT Part No	DESCRIPTION
	1450070170	Piston Ring RHB7 (Comp Small)
041T-008	1450052100	Bearing (Short 6mm) RHB5 (USA P/N)
041T-010	1450052101	Bearing (Long 7mm) RHB5(USA. P/N)
070T-017	1450052170	Piston Ring (Comp Large) RHB5 (USA P/N)
070T-020	1450052160	Piston Ring (Turbine End) RHB5 (USA P/N)
070T-022	1450052175	Piston Ring (Comp Small) RHB5
NN133505	1450052320	Thrust Bearing (RHB5) Old Number
NB133206	1450052620	Screws (T/Bearing Ret.) RHB5
NB133208	1450052610	Screws (Insert Retainer) RHB5
NN131108	1450052350	Shaft Nut (RHB5)
NN131575	1450052160	Piston Ring (Turbine End) RHB5 (EUR. P/N)
NN131576	1450052170	Piston Ring (Comp Large) RHB5(Euro. P/N)
NN131577	1450052175	Piston Ring (Comp. End) RHB3/5
NN133208	1450052140	Snap Ring (Bearing Ret.)RHB5
NN133504	1450052100	Bearing (Short 6mm) RHB5 (EUR. P/N)
NN133506	1450052101	Bearing (Long 7mm) RHB5(EUR. P/N)
NN133515	1450052101	Bearing (Long 7mm) RHB5(EUR. P/N)
NN133571	1450052100	Bearing (Short 6mm) RHB5 (EUR. P/N)
NN133591	1450052320	Thrust Bearing (RHB5)
NN133596	1450052320	Thrust Bearing (RHB5)
NN139921A	1450052750	Service Kit RHB52 (Short Brg)
NN139922A	1450052751	Service Kit RHB52 (Long Brg)



KKK - MELETT Cross Reference

To quickly find a part, use the ctrl+F option. If the part you require is not found, please contact Melett direct with you enquiry.

Melett Ltd
Tel: +44 (0)1924 488686
Fax: +44 (0)1924 459200
Email: sales@melett.com

Melett 2002. All manufacturers names, numbers, symbols and descriptions used herein are for reference purposes only and do not imply that any part listed is the product of these manufacturers.

KKK Part No.	MELETT Part No	DESCRIPTION
	1301014180	Piston Ring(Std 14mm) O/S.14.1mm O/D
	1302003320	K03 (5303-970-0003) Thrust Bearing
	1301014124	Bearing K14/16 +010"OD/Std ID
	1301014120	Bearing K14/16 +010"OD/-010"ID
	1301014127	Bearing K14/16 Std OD/+.010" ID
	1301027180	Piston Ring K27 te +.008wide
	1301014117	Bearing K14/16 Std OD / +.005"ID
	1301014110	Bearing K14/16 +005"OD/-005"ID
	1302004101	Bearing K03/K04 Std
	1301014114	Bearing K14/16 Std ID / +.005"OD
	1301036425	Comp Wheel K361 4064 ND
1301027351	1301027351	Shaft Nut (K24/26/27) (Int. with 5327-128-0202)
1301027352	1301027352	Shaft Nut 6 mm RHT (K24/26/27) MELETT Numbers 1301027350 / 351 / 352
500-35-19-2601	1301026620	Cap screws K26/27/ S/P to B/Hsg
500-35-19-2627	1301036620	Bolt (K36 Seal Plate)
500-35-35-5219	1301027610	Bolt (K27/K33/H2C/Garrett (Int. with 500-35-35-5222)
500-35-35-5222	1301027610	Bolt (K27/K33/H2C/Garrett Int. with 5222-109-0403)
500-35-36-0301	1301027600	Bolt (K27/T3 Turbine HT) Int. with 500-35-36-0327
500-35-36-0327	1301027600	Bolt (K27/T3 Turbine HT) Int. with 500-35-36-0301
500-35-36-0328	1301027600	Bolt (K27/T3 Turbine HT)
500-35-36-0331	1301036610	Bolt (K34/36 C/Hsg to Seal plate)
500-35-36-0468	1301036600	Bolt (K36 Turbine HT)
500-40-79-0007	1301014140	Snap Ring
5003-519-2601	1301026620	Cap screws K26/27/ S/P to B/Hsg
5003-536-0280	1301026600	Set Bolts K26 Turbine
5003-584-0900	1301026610	Set Bolt K26 C/Hsg to S/Plate
5220-109-0201	1200050630	Washer (2 Piece clamp Plate)
5221-128-0203	1250040350	Shaft nut (4LE/F/GK)
5222-101-5001	1250403800	Comp Cover 259 / 3LD9 8 x M6-6H
5222-103-0601	1301027580	Spring Washer (K27 C/Hsg) 6mm
5222-109-0201	1200050630	Washer (2 Piece clamp Plate)
5222-109-0402	1250403561	Bolt
5222-109-0403	1301027610	Bolt (K27/K33/H2C/Garrett)(Int. with 500-35-35-5222)
5222-109-5201	1250403645	V Clamp
5222-120-2112	1150403435	Shaft & Wheel 3LD (2x Piston Ring Grooves)
5222-123-2007	1250403425	C/Wheel 259 / 3LD9
5222-124-0000	1250403240	Thrust Ring 3LD
5222-127-0100	1150400160	Piston Ring Stainless
5222-127-0103	1150400160	Piston Ring (HCSKM)
5222-127-0400	1250403200	Flinger 3LD
5222-128-0200	1100120350	Shaft Nut. T12
5222-128-0202	1100120350	NUT (use1100120350)
5222-150-0000	1150403452	Bearing Housing 3LD (Smooth bore - metric)
5222-155-1000	1250403100	Bearing 3LD (Std)
5222-155-1301	1250403320	Thrust Bearing 3LD
5222-156-0800	1250403310	Oil Deflector 3LD
5222-158-0501	1250030150	O Ring (Insert HSKM)
5222-158-0508	1250030150	O Ring (Insert HSKM)
5222-711-0001	1300403751	Repair Kit . Major (3LD KKKstep bore)
5223-101-6320	1301027850	T/Hsg K27 6.11 Single Entry Bolted Outlet

5223-101-6322	1301027851	T/Hsg K27 9.11 Single Entry Bolted Outlet
5223-101-6323	1301027852	T/Hsg K27 11.11 Single Entry Bolted Outlet
5223-101-6522	1301027880	T/Hsg K27 13.21 Twin Entry Piston Ring Outlet
5223-108-0500	1250404155	O Ring C/End 4LGZ
5223-109-0802	1301027480	Clamp Plate (K27/3LKZ Turb)
5223-109-0804	1301027500	Clamp Plate (3LD/3LEP/K27 Comp.)
5223-109-0806	1301027480	Clamp Plate (K27/3LKZ Turb) ssb 5223-109-0807
5223-109-0807	1301027480	Clamp Plate (K27/3LKZ Turb) ss 5223-109-0806
5223-127-0100	1150400170	Piston Ring (HSKM)
5223-127-0102	1301027160	Piston Ring K26 Turb. & Comp.
5223-157-0400	1152302140	SNAP RING H2C / 3LKS
5230-123-2001	1250040400	Comp Wheel 4LE 302 Radial
5230-123-2007	1250040400	Comp Wheel 4LE 302 Radial
5230-157-0400	1301036140	Snap Ring (H.S.K)
5232-120-2125	1152303435	Shaft & Wheel (HC3/K361) UNF T3
5232-120-2130	1152303436	Shaft & Wheel (4LG UNF T2)
5232-127-0100	1150400170	Piston Ring
5232-127-0100	1150400172	Piston Ring
5232-127-0101	1150400172	Piston Ring
5232-127-0104	1150400170	Piston Ring
5232-127-0402	1150504200	Flinger Sleeve 4LE 2 ring groove (MELETTx 2 parts)
5232-127-0500	1301036220	Spacer Sleeve (4LE/K36)
5232-127-0601	1301036240	Thrust Ring (K36)
5232-128-0202	1250040350	Shaft nut (4LE/F/GK) (7/16" - 20X8.5 SW17)
5232-152-3000	1250403300	Insert Plate
5232-152-3001	1250403300	Insert Plate
5232-155-0600	1250040260	Oil Control Sleeve (4LE)
5232-155-1003	1250040100	Bearing (4LE- HC3 -HT3B -K361) Std OD/ Std ID
5232-155-1303	1250040320	Thrust Bearing (4L-/HC3/3LKS) Interchangeable with 5252-155-1301
5232-157-0000	1250403140	Snap Ring
5232-158-0500	1250040155	O Ring (4LE/F/GK) C/Hsg to B/Hsg
5232-711-0004	1301504750	Service Kit 4LE/4LF/4LGZ
5240-109-5300	1100120645	Nut. V Band clamp. T12
5240-155-0603	1250404260	Oil Control Sleeve 4B, 4MD, 4HD
5240-155-1003	1250404100	BearingStd OD/ Std ID Int. Change with 5240-155-1004
5240-155-1004	1250404100	BearingStd OD/ Std ID Int. Change with 5240-155-1003
5240-157-0400	1250404140	Snap Ring
5240-165-1047	1250404901	Noz Ring 4MD (.246)
5240-165-1049	1250404900	Noz Ring 4MD (.318)
5240-167-0000	1250404142	Snap Ring
5252-124-0000	1301036240	Thrust Ring (4LG) (K36)
5252-155-1301	1250040320	Thrust Bearing (4L-/HC3/3LKS) Interchangeable with 5232-155-1303
5303-123-2011	1302003401	K03 Compressor wheel
5303-711-0000	1302003751	K03/K04 Repair Kit
5303-711-0001	1302003751	K03/K04 Repair Kit
5314-109-5801	1301014501	Clamp Plate (K14 Comp end - Short)
5314-109-5803	1301014500	Clamp Plate (K14 Comp end - Long)
5314-109-5806	1301014480	Clamp Plate (K14 Turbine end) use 5314-109-5818
5314-109-5813	1301014481	Clamp Plate K14 Turbine end (Forged)
5314-109-5818	1301014480	Clamp Plate (K14 Turbine end) useto repace 5314-109-5806
5314-120-2014	1301014436	Shaft & Wheel K14
5314-120-2101	1301014435	Shaft and Wheel (K14) ssb 5314-120-2111 RHT
5314-120-2111	1301014435	Shaft and Wheel (K14) ss 5314-120-2101 RHT
5314-123-2000	1301014400	Comp. Wheel (K14) 2060GGA ssb 5314-123-2005
5314-123-2005	1301014400	Comp. Wheel (K14) 2060GGA ss 5314-123-2000
5314-127-0100	1301014160	Piston Ring (K14 - K27)
5314-128-0200	1401404350	Shaft nut K14/K16 ssb 5314-128-0202 R/H/Thread
5314-128-0201	1401404350	Shaft nut K14/K16 ssb 5314-128-0202 R/H/Thread
5314-128-0202	1401404350	Shaft nut K14/K16 ss 5314-128-0200/1R/H/Thread
5314-155-1003	1301014100	Bearing K14 / K16 Std.
5314-155-1300	1301014320	Thrust Bearing K14 (280 Deg) (Use 5314-155-1302)
5314-155-1301	1301014320	Thrust Bearing K14 (280 Deg) (Use 5314-155-1302)
5314-155-1302	1301014320	Thrust Bearing K14 360 Deg (Int. with 5314-155-1300/01)
5314-158-0500	1301014151	O Ring (K14) S/P to C/H 102.0
5314-158-0501	1301014150	O Ring
5316-109-5809	1301016481	Clamp Plate K16 Turbine end (Forged)
5316-120-2101	1301016435	Shaft & Wheel (K16) ss 5316-120-2103 RHT
5316-120-2103	1301016435	Shaft & Wheel (K16) ssb 5316-120-2101 RHT
5316-123-2000	1301016415	Comp. Wheel K16 (FB) 2260G ssb 5316-123-2005

5316-123-2001	1301016400	Comp. Wheel (K16) 2267GGA ssb 5314-123-2003
5316-123-2003	1301016400	Comp. Wheel (K16) 2267GGA ss 5314-123-2001
5316-123-2005	1301016415	Comp. Wheel K16 (FB) 2260G ss 5316-123-2000
5316-158-0500	1301016151	O Ring (K16) S/P to C/H
5324-711-0500	1301027766	Thrust/Spacer/Flinger Kit K24/26/27/28/29 (19.3)
5326-109-5801	1301026500	Clamp Plate K26 Comp. Housing
5326-124-0000	1301027240	Thrust Ring (K26/K27)
5326-127-0101	1301014160	Piston Ring
5326-127-0102	1301014160	Piston Ring (K14 - K27)
5326-127-0103	1301014160	Piston Ring (K14 - K27)
5326-127-0402	1301027200	Thrust Spacer/Flinger (K26/27)
5326-127-0500	1301027220	Spacer sleeve (K26/K27)
5326-128-0201	1301027350	Shaft Nut (K27)
5326-128-0206	1301027350	Shaft Nut (K24/26/27)
5326-128-0208	1301027350	Shaft Nut (K24/26/27)
5326-128-0209	1301027352	Shaft Nut (K24/26/27)
5326-128-5000	1301027356	Shaft nut LHT 7mm ss 5327-128-5001 MELETT 1301027355
5326-155-1001	1301027101	Bearing (Grooved O.D. K27)
5326-155-1002	1301027100	Bearing (Smooth O.D. K27)
5326-155-1003	1301027101	Bearing (Grooved O.D. K27)
5326-155-1004	1301027100	Bearing (Smooth O.D. K27)
5326-155-1302	1301027320	Thrust Bearing (K27) use 1301073200
5326-155-1303	1301027320	Thrust Bearing (K27) (interchangable with 5326-155-1304)
5326-155-1304	1301027320	Thrust Bearing (K27) (interchangable with 5326-155-1303)
5326-155-1305	1301027321	Thrust Bearing 360 Deg. K26-27-28-29
5326-156-0800	1301027310	Oil Deflector (K26/K27)
5326-157-0400	1100040140	Snap Ring (thick)
5326-158-0500	1301026150	O Ring (K26) C/Hsg to S/ Plate
5327-101-5032	1301027800	Comp. Housing K27-3070G
5327-101-5035	1301027802	Comp Housing K27 3060G
5327-101-5036	1301027801	Comp Housing K27 3064G
5327-101-6300	1301027870	T/Hsg K27 6.11 Single Entry Piston Ring Outlet
5327-101-6500	1301027860	T/Hsg K27 17.21 Twin Entry Bolted Outlet
5327-101-6508	1301027861	T/Hsg K27 21.21 Twin Entry Bolted Outlet
5327-101-6515	1301027881	T/Hsg K27 17.21 Twin Entry Piston Ring Outlet
5327-109-0000	1301027520	Lock Plate (K27 Turb.)
5327-120-2103	1301027435	Shaft & Wheel (K27 F/Back C/W) RHT ssb 5327-120-5013 LHT
5327-120-2105	1301027435	Shaft & Wheel (K27 F/Back C/W) RHT ssb 5327-120-5013 LHT
5327-120-2107	1301027435	Shaft & Wheel (K27 F/Back C/W) RHTssb 5327-120-5013 LHT
5327-120-2108	1301027436	Shaft & Wheel (K27 F/Back C/W) RHTssb 5327-120-5000 LHT
5327-120-2110	1301027438	Shaft & Wheel K27 RHT ssb 5327-120-5005 LHT
5327-120-2111	1301027437	Shaft & Wheel K27 (11/21) RHTssb 5327-120-5006 LHT
5327-120-2112	1301027436	Shaft & Wheel K27 (S/B C/W) RHT ssb 5327-120-5000 LHT
5327-120-2113	1301027438	Shaft & Wheel K27 RHT ssb 5327-120-5005 LHT
5327-120-2117	1301027438	Shaft & Wheel K27 RHT ssb 5327-120-5017 LHT
5327-120-2121	1301027437	Shaft & Wheel K27 (11/21) RHT ssb 5327-120-5011 LHT
5327-120-5000	1301027436	Shaft & Wheel K27 (S/BC/W) RHT ss 5327-120-2112 LHT use 1301027436
5327-120-5005	1301027438	Shaft & Wheel K27 LHT use 1301027438 RHT use 1301027438
5327-120-5006	1301027437	Shaft & Wheel K27 (11/21) LHTss5327-120-2111 use 1301027437 RHT
5327-120-5011	1301027437	Shaft & Wheel K27 (11/21) LHTss5327-120-2121 RHTuse 1301027437 RHT
5327-120-5013	1301027435	Shaft & Wheel (K27 F/Back C/W) RHTss 5327-120-2103/05/07 LHT
5327-120-5017	1301027438	Shaft & Wheel K27 LHT ss 5327-120-2117 RHTuse 1301027438
5327-123-2000	1301027402	Comp.Wheel K27 Radial 2963U (Radial)ssb 5327-123-2234
5327-123-2002	1301027406	Comp. Wheel K27 B/Curved 2970N
5327-123-2003	1301027401	Comp.Wheel K27 Radial 2960
5327-123-2006	1301027405	Comp. Wheel K27 Radial 2966V
5327-123-2009	1301027400	Comp Wheel K27 B/Curved 3060G
5327-123-2010	1301027400	Comp Wheel K27 B/Curved 3060G
5327-123-2012	1301027403	Comp Wheel K27 B/Curved 3064G
5327-123-2015	1301027404	Comp Wheel K27 B/Curved 3070G ssb 5327-123-2303
5327-123-2021	1301027415	Comp. Wheel K27 3262MAA Back curve F/bk
5327-123-2035	1301027425	Comp. Wheel K27Bcur Sbk3262MGB
5327-123-2217	1301027425	Comp. Wheel K27 Bcur Sbk3262MGB
5327-123-2227	1301027425	Comp. Wheel K27 Bcur Sbk3262MGB
5327-123-2234	1301027402	Comp.Wheel K27 Radial 2963U (Radial)ss 5327-123-2000
5327-123-2236	1301027406	Comp. Wheel K27 B/Curved 2970N
5327-123-2237	1301027401	Comp.Wheel K27 Radial 2960
5327-123-2238	1301027405	Comp. Wheel K27 Radial 2966V
5327-123-2301	1301027400	Comp Wheel K27 B/Curved 3060G

5327-123-2302	1301027403	Comp Wheel K27 B/Curved 3064G
5327-123-2303	1301027404	Comp Wheel K27 B/Curved 3070G ss 5327-123-2015
5327-127-0100	1301027160	Piston Ring K26 Turb. & Comp.
5327-128-0200	1301027350	Shaft Nut (K24/26/27)
5327-128-0202	1301027351	Shaft Nut (K24/26/27) (Int. with 5327-128-0205)
5327-128-0205	1301027351	Shaft Nut (K24/26/27) (Int. with 5327-128-0202)
5327-128-5001	1301027355	Shaft nut LHT 7mm ssb 5326-128-5000 MELETT 1301027356
5327-150-0001	1301027450	Bearing Housing (K27 L/Turb)
5327-150-0004	1301027450	Bearing Housing (K27 L/Turb)
5327-150-0006	1301027450	Bearing Housing (K27 L/Turb)
5327-150-0010	1301027450	Bearing Housing (K27 L/Turb)
5327-150-0012	1301027455	Bearing Housing (K27 S/Turb)
5327-150-0016	1301027455	Bearing Housing (K27 S/Turb)
5327-151-5700	1301027361	Seal Plate (K27) ssb 5327-151-5707
5327-151-5706	1301027360	Seal Plate (K27)
5327-151-5707	1301027361	Seal Plate (K27) ssb 5327-151-5734
5327-151-5710	1301027360	Seal Plate (K27)
5327-151-5715	1301027362	Seal Plate K27 PSB0002 (83.8 C/W)
5327-151-5730	1301027360	Seal Plate (K27)
5327-151-5732	1301027362	Seal Plate K27 PSB0002 (83.8 C/W)
5327-151-5734	1301027361	Seal Plate (K27)ss 5327-151-5707
5327-158-0500	1301027150	O Ring (K27 Comp. Hsg.)
5327-158-0501	1301027151	O Ring
5327-165-2000	1301027340	Turbine Back Plate (K27) (Cast)ssb5327-165-2002
5327-165-2002	1301027340	Turbine Back Plate (K27) (Cast)ss5327-165-2000
5327-165-2003	1301027341	Heat Shield (Pressing)
5327-165-2005	1301027342	Turbine Back Plate (K27) Stain/Steel Pressing (Medium dia)□edium)
5327-710-0002	1301027703	Core Assy K27-2963U
5327-710-0008	1301027700	Core Assy K27-2960U
5327-710-0009	1301027704	Core Assy K27-2970N
5327-710-0014	1301027701	Core Assy K27-3060G ssb 5327-710-0101
5327-710-0019	1301027702	Core Assy K27-3064G
5327-710-0025	1301027702	Core Assy K27-3064G
5327-710-0031	1301027714	Core Assy K27-3070G
5327-710-0044	1301027711	Core Assy K27-3060G StH/Shield
5327-710-0073	1301027724	Core Assy K27 (3262) Use MELETT 1301027724 replacement core
5327-710-0085	1301027725	Core Assy. K27-3464MOA
5327-710-0101	1301027701	Core Assy K27-3060G ss 5327-710-0014
5327-710-0130	1301027714	Core Assy K27-3070G
5327-710-0501	1301027712	Core Assy (BMW 745i)
5327-711-0015	1301027758	Service Kit K27 9Gro. Brgs- 3 P/Rings ssb5328-711-0009
5327-711-0053	1301027760	Service Kit K27
5328-158-0500	1301028150	O Ring K28
5328-159-3300	1301027581	Washer (K27 Seal Plate)
5328-711-0009	1301027758	Service Kit K27 9Gro. Brgs- 3 P/Rings ss 5327-711-0015
5331-155-1000	1301033100	BearingK31/ K33 (Small) ss 5333-155-1000
5331-158-0502	1301028150	O Ring K31
5333-124-0001	1301033240	Thrust Ring K33 (Small Bore)
5333-155-1000	1301033100	Bearing K33 (Small) ssb 5331-155-1000
5334-101-5002	1301036804	Comp. Housing K34/36 3772V
5334-109-0000	1301036520	Lock Plate (K34/K36 Turb.)
5334-109-0800	1301036500	Clamp Plate (K34/K36 Comp.)
5334-123-2001	1301036402	Comp Wheel K36 Radial 3763
5334-123-2002	1301036400	Comp Wheel K34/36 Radial 3766
5334-123-2003	1301036404	Comp. Wheel K34/36 Radial 3770
5334-123-2004	1301036401	Comp Wheel K34/36 Radial 3772
5334-123-2008	1301036403	Comp Wheel K36 Radial 3566
5334-150-0002	1301036450	Bearing Housing (K36)
5334-151-5700	1301036360	Seal Plate K34/36 MNA 104mm
5334-158-0500	1301036150	O Ring (K34/K36) Comp.Hsg.
5334-165-2000	1301036340	Turbine Back Plate K36 (Cast)
5336-101-5006	1301036823	Comp. Housing K36 4064MNA
5336-101-5008	1301036824	Comp. Housing K36 4067MNA
5336-101-5014	1301036825	Comp. Housing K36 4067MNA
5336-101-6508	1301036867	Turbine Housing K36 35.21
5336-101-6511	1301036864	Turbine Housing K36 25.22
5336-101-6513	1301036866	Turbine Housing K36 27.22
5336-120-2101	1301036435	Shaft and Wheel Small Trim (K36)
5336-120-2102	1301036436	Shaft and Wheel Large Trim (K36)

5336-120-2103	1152303435	Shaft & Wheel (HC3/K361) UNF T3
5336-120-2104	1301036437	Shaft and Wheel (K36)
5336-120-2106	1152303435	Shaft & Wheel (HC3/K361) UNF T3
5336-120-2109	1301036437	Shaft & Wheel K36 for S/B C/W ssb 5336-120-2119
5336-120-2117	1152303436	Shaft & Wheel (K361 UNF T2)
5336-120-2119	1301036437	Shaft & Wheel K36 for S/B C/W ss 5336-120-2109
5336-123-2000	1301036425	Comp Wheel K361 4064 ND
5336-123-2001	1301036416	Comp Wheel K36 Bc Fbk 4064ND ss 5336-123-2005
5336-123-2005	1301036416	Comp Wheel K36 Bc Fbk 4064MNA ssb 5336-123-2001
5336-123-2008	1301036415	Comp Wheel K36 Bc Fbk 4060MNA
5336-123-2012	1301036420	Comp Wheel K36 4067MNA ssb 5336-123-2032
5336-123-2013	1301036421	Comp Wheel K36 4070MNA ssb 5336-123-2033
5336-123-2021	1301033400	Comp. Wheel K36-4064 MNA SBkSb
5336-123-2032	1301036420	Comp Wheel K36 4067MNA ss 5336-123-2012
5336-123-2033	1301036421	Comp Wheel K36 4070MNA ss 5336-123-2013
5336-128-2104	1301036350	Shaft Nut (K36)
5336-155-1000	1250040100	Bearing (4LE- HC3 -HT3B -K361) Std OD/ Std ID Interchangeable with 5232-155-1000
5336-155-1003	1250040100	Bearing (4LE- HC3 -HT3B -K361) Std OD/ Std ID
5337-109-5800	1301036480	Clamp Plate (K36 Turb.)
5337-127-1000	1301036260	Oil Control Ring (K36)
5337-137-0401	1301036200	Flinger (2 x Piston ring grooves)
5337-151-5713	1301037360	Seal Plate K37 (114)
5337-155-1000	1301036100	Bearing Std. (K36)
5337-155-1001	1301036100	Bearing Std. (K36)
5337-155-1301	1301036320	Thrust Bearing (K36)
5337-156-0800	1301036310	Oil Deflector (K36)
5337-159-3300	1301036581	Washer (Seal Plate) M8.4
5342-158-0500	1301033150	O Ring (B/Hg to S/P K33/34/36) 94.50x3.00
5636-109-5300	1301026640	Lock nut K26 Turbine
5900-129-0200	1301014620	Cap Screw (K14/16) S/P to B/H
5900-129-0201	1301026620	Cap screws K26/27/ S/P to B/Hsg
5900-129-0202	1301014620	Cap Screw (K14/16) S/P to B/H
5900-129-0206	1301026620	Cap screws K26/27/ S/P to B/Hsg
not known	1302003170	Piston Ring (Comp. End K03 / K04)



KOMATSU - MELETT Cross Reference

To quickly find a part, use the ctrl+F option. If the part you require is not found, please contact Melett direct with you enquiry.

Melett Ltd

Tel: +44 (0)1924 488686

Fax: +44 (0)1924 459200

Email: sales@melett.com

Melett 2002. All manufacturers names, numbers, symbols and descriptions used herein are for reference purposes only and do not imply that any part listed is the product of these manufacturers.

Komatsu Part No.	MELETT Part No	DESCRIPTION
	1350110750	Repair Kit KTR110 (Std Bearing)
	1350130761	Repair Kit KTR130 (Std Bearing + Thrusts + Insert)
	1350130760	Repair Kit KTR130 (Std Bearing + Thrusts+ Insert)
	1350130758	Repair Kit KTR130 (Std OD/-0.010" ID + Thrusts)
	1350110758	Repair Kit KTR110 (Std OD/-0.010" ID + Thrusts)
	1350130757	Repair Kit KTR130 (+.010"/Std ID+ Thrusts)
	1350110757	Repair Kit KTR110 (+.010"/Std ID+ Thrusts)
	1350110756	Repair Kit KTR110 (+.010"/-0.010"+ Thrusts)
	1350130762	Repair Kit KTR130 (+.010"/-0.010"+ Thrusts + Insert)
	1350130755	Repair Kit KTR130 (Std Bearing + Thrusts)
	1350130756	Repair Kit KTR130 (+.010"/-0.010"+ Thrusts)
	1350110755	Repair Kit KTR110 (Std Bearing + Thrusts)
	1350110753	Repair Kit KTR110 (Std OD/-0.010" ID)
	1350110752	Repair Kit KTR110 (+.010"/Std ID)
	1350130753	Repair Kit KTR130 (Std OD/-0.010" ID)
	1350130752	Repair Kit KTR130 (+.010"/Std ID)
	1350110751	Repair Kit KTR110 (+.010"/-0.010")
	1350130751	Repair Kit KTR130 (+.010"/-0.010")
	1350110120	Bearing KTR110 +.010"OD/-0.010"ID
	1350111150	O Ring (B/Hsg to Seal Plate KTR110G)
	1350130127	Bearing KTR130 Std Bore/-0.010" ID
	1350130750	Repair Kit KTR130 (Std Bearing)
	1350130763	Repair Kit KTR130 (Std OD/-0.010" ID + Thrusts + Insert)
	1350111124	Bearingn KTR110G +.010"OD/Std ID
	1350111127	Bearing KTR110G Std OD/-0.010"ID
	1350110124	Bearing KTR110 +.010"OD/Std ID
	1350111120	Bearing KTR110G +.010"OD/-0.010"ID
	1350130120	Bearing KTR130 +0.010" OD/-0.010"ID
	1350130124	Bearing KTR130 +0.010" OD/Std Bore
	1350110127	Bearing KTR110 Std OD/-0.010" ID
01010-30625	1350130621	BoBolt insert Plate KTR130 Super Back
01010-30630	1350130620	Bolt insert Plate KTR130 Flat Back
01010-30816	1301027600	Bolt KTR110 Seal Plate
01010-61016	1301036600	Bolt (Turbine HT)
07000-62055	1350110150	O Ring (Insert) KTR110
07000-63095	1350130150	O Ring (KTR130 Insert Plate)
6501-11-1650	1101461550	Lock Plate KTR130 Insert plate

6502-12-1312	1350130240	Thrust Collar KTR130
6502-12-1334	1350130200	Flinger Sleeve KTR130 (single ring)
6502-12-1340	1350130160	Piston Ring (Turb) KTR130 same as 1350130170
6502-12-1620	1350130100	Bearing (Std.) KTR130
6502-12-1630	1350130320	Thrust Bearing KTR130
6502-12-1631	1350130320	Thrust Bearing KTR130
6502-12-1640	1350130300	Insert Plate KTR130 Flat Back
6502-14-1340	1350130160	Piston Ring (Turb) KTR130 same as 1350130170
6502-14-1620	1350130100	Bearing (Std.) KTR130
6502-30-1640	1350130301	Insert Plate KTR130 Super Back
6505-11-0110	1350110100	Bearing KTR 110
6505-11-0111	1350110100	Bearing KTR 110
6505-11-0112	1350110100	Bearing KTR 110
6505-11-0150	1350110320	Thrust Bearing KTR 110
6505-11-0210	1350110240	Thrust Ring/Spacer KTR110
6505-11-0250	1350110200	Thrust Collar KTR110
6505-11-0310	1350110160	Piston Ring KTR 110 (Turb)
6505-11-0350	1350110170	Piston Ring KTR 110 (Comp)
6505-51-0150	1350111320	Thrust Bearing KTR 110G
6505-51-0151	1350111320	Thrust Bearing KTR 110G
6505-51-0310	1350111160	Piston Ring (Turb.) KTR110G
6505-51-0351	1350111170	Piston Ring (Comp.) KTR110G



MHI - MELETT Cross Reference

To quickly find a part, use the ctrl+F option. If the part you require is not found, please contact Melett direct with you enquiry.

Melett Ltd
Tel: +44 (0)1924 488686
Fax: +44 (0)1924 459200
Email: sales@melett.com

Melett 2002. All manufacturers names, numbers, symbols and descriptions used herein are for reference purposes only and do not imply that any part listed is the product of these manufacturers.

MHI Part No.	MELETT Part No	DESCRIPTION
	1401635100	Bearing Std TD035/TF035
	1401404181	Piston Ring TD04 T/end +.010"WIDE
	1401404180	Piston Ring TD04 T/end +.010"OD
	1401635110	Bearing +0.005"OD/-0.005"ID TD-TF035
	1401635117	Bearing Std OD/-0.005"ID TD-TF035
	1401704400	Comp. Wheel TG04-12T
	1401404124	Bearings (TD04) +010" OD/std ID
49160-11100	1250404340	Heat Shield
49160-12500	1250404142	Snap Ring
49160-13100	1100120645	Nut. V Band clamp. T12
49160-14100	1250404345	V Band Clamp T/Hsg 7" 4MD
49160-14200	1250404346	V Band Clamp Assy Comp/Hsg 9"
49160-15800	1250404901	Noz Ring 4MD (.246)
49160-15901	1250404900	Noz Ring 4MD (.318)
49160-20100	1250404450	B/Hsg Oil inlet and outlet UNC without threaded mtg bosses on side
49160-21500	1250404320	Thrust Bearing 4MD
49160-22100	1250404260	Oil Control Sleeve 4B, 4MD, 4HD
49160-22200	1250404310	Oil Deflector 4MD
49160-22501	1250404300	Insert Plate 4MD 4HD
49160-22603	1250404330	Spacer Plate
49160-23100	1250404141	Snap Ring TD04
49160-23100	1250404141	Snap Ring 4HD
49160-23200	1250404140	Snap Ring
49160-23300	1150400170	Piston Ring (HSKM)
49160-23400	1250404150	O Ring 4MD
49160-23500	1100120610	Bolt. (Insert Plate) T12
49160-23600	1250404630	Spring Washer, lock tab, Thrust bearing
49160-23700	1150400172	Piston Ring
49160-30500	1250404435	Shaft and Wheel 4MD
49160-40100	1250404409	C/W 4MD-754
49160-40200	1250404400	Compressor Wheel 4MD-351
49160-40300	1250404402	Compressor Wheel 4MD-354
49160-40400	1250404404	Compressor Wheel 4MD-454
49160-40600	1250404411	C/W 4MD-755 also 4HD
49160-42100	1250404200	Flinger Sleeve
49160-42300	1250404220	Spacer Sleeve
49160-42400	1250404250	Shim 0.003
49160-42500	1250404251	Shim 0.005"
49160-42700	1250404350	Shaft Nut 4MD
49160-42800	1250404350	Shaft Nut 4MD
49160-51100	1250404155	O Ring C/End 4MD
49161-42200	1250404240	Thrust Ring

49162-21100	1250040100	Bearing (4LE- HC3 -HT3B -K361) Std OD/ Std ID
49162-21500	1250040320	Thrust Bearing (4L-/HC3/3LKS)
49162-21600	1250040320	Thrust Bearing (4L-/HC3/3LKS)
49162-21700	1250040320	Thrust Bearing (4L-/HC3/3LKS)
49162-21800	1250040320	Thrust Bearing (4L-/HC3/3LKS)
49162-22500	1250403300	Insert Plate
49162-23100	1301036140	Snap Ring (H.S.K) TD09
49162-23200	1250403140	Snap Ring
49162-23400	1250030150	O Ring (Insert HSKM)
49162-23600	1250030150	O Ring (Insert HSKM)
49162-40401	1250504401	Comp Wheel 4LE 504 Radial
49162-42200	1301036240	THRUST RING (use 1301036240)
49162-42300	1301036220	Spacer Sleeve (4LE/K36)
49162-42400	1150504200	Flinger Sleeve 4LE 2 ring groove (MELETTx 2 parts)
49162-42700	1250040350	Shaft nut (4LE/F/GK)
49164-22200	1250403310	Oil Deflector 3LD
49164-23300	1150400160	Piston Ring (HCSKM)
49164-23700	1150400160	Piston Ring Stainless TD09
49164-53100	1301027500	Clamp Plate (3LD/3LEP/K27 Comp.)
49166-21502	1250403321	Thrust Bearing 3LM
49166-22502	1150513300	Insert Plate 3FJ/3LM
49166-23300	1401404160	Piston Ring TD04 Turbine End
49166-42700	1100120350	Shaft Nut
49167-23100	1150400172	Piston Ring
49167-42200	1301036240	THRUST RING 4LE
49168-22100	1401405150	O Ring TC05/06, TD05/06 (Insert Plate)
49168-42200	1100040350	Shaft Nut TC05/6, TD05/06
49168-80400	1401306750	Service Kit MHI TC06
49170-23100	1401405170	Piston Ring (T) Std Hi temp TC05/06, TD05/06
49171-41410	1401404400	Comp. Wheel (TD04-9B)
49171-41510	1401404401	Comp. Wheel MHI (TD04-11B)
49172-23200	1401404170	Piston Ring (C) TC04, TD04, TE04H
49173-22500	1401404300	Insert /Seal Plate (MHI TD04) Small hole
49177-08020	1401404700	Core Assy MHI (TD04-9B) Shogun
49177-09600	1401404701	Core Assy MHI (TD04-11B) BMW
49177-15122	1401404891	Turbine Housing Assy TD04-4CM2 SSB 49377-15200
49177-20310	1401404451	Bearing Housing MHI TD04 (Air cooled) BMW
49177-21100	1401404100	Bearing TD04, TE04H (std)
49177-21600	1401404320	Thrust Bearing TD04, TE04H
49177-22100	1401404155	O Ring (TD04 B/Hsg / Chsg)
49177-22200	1401404150	O Ring (Seal Plate TD04)
49177-22300	1401404140	Snap Ring TD04, TE04H
49177-23100	1401404160	Piston Ring TC04, TD04, TC05/06, TD08/08H, TE04H
49177-25100	1401404450	Bearing Housing MHI TD04 (Air cooled) Shogun
49177-25300	1401404451	Bearing Housing MHI TD04 (Air cooled) BMW
49177-25310	1401404451	Bearing Housing MHI TD04 (Air cooled) BMW
49177-30120	1401404435	Shaft & Wheel TD04-9(Shogun) ssb 49177-30130
49177-30130	1401404437	Shaft & Wheel TD04-9(Shogun) ss 49177-30120 (Melett 1401404435)
49177-30300??	1401404438	Shaft & Wheel MHI TD04-15G (Volvo)
49177-42100	1401404200	Sleeve Guide TE04H
49177-42200	1401404350	Shaft nut TD04 R/H/Thread
49177-80400	1401404753	Service Kit TD04 (MELETT Major KIT R/H & L/H thread Nut)
49177-80405	1401404750	Service Kit TD04 (R/H thread Nut)
49178-21100	1401405100	Bearing Std/Std TD05/06 (Std)
49178-21400	1401405100	Bearing Std/Std TD05/06 (Std)
49178-21500	1401405320	Thrust Bearing TD05/06
49178-21600	1401405320	Thrust Bearing TD05/06
49178-22300	1100040140	Snap Ring TD05/06
49178-23100	1401405160	Piston Ring TC05/06, TD05/06, TD09
49183-21100	1401404100	Bearing TD04, TE04H (std)
49183-30100	1401404436	Shaft & Wheel TD04 -13 (Volvo)
49377-15200	1401404891	Turbine Housing Assy TD04-4CM2 SS 49177-15122

49377-15500	1401404890	Turbine Housing Assy TD04-4CM2
49377-15530	1401404892	Turbine Housing (Water Cooled Turbo - 02513)
49460-42600	1250404252	Shim 0.010"
F3153-10000	1401405155	O Ring TC05/06, TD05/06 (C/Hsg)
ME71927*	1152303170	Piston Ring



SCHWITZER - MELETT Cross Reference

To quickly find a part, use the ctrl+F option. If the part you require is not found, please contact Melett direct with you enquiry.

Melett Ltd

Tel: +44 (0)1924 488686

Fax: +44 (0)1924 459200

Email: sales@melett.com

Melett 2002. All manufacturers names, numbers, symbols and descriptions used herein are for reference purposes only and do not imply that any part listed is the product of these manufacturers.

Schwitzer Part No.	Melett Part No.	DESCRIPTION
	1252212124	Bearing S2B (Long) OD +.010" / ID Std
	1252139117	Bearing S3A Standard OD / -.005" ID
	1252202127	Bearing S2B (Short) OD Std / ID +.010"
	1252202120	Bearing S2B (Short) OD +.010" / ID -.010"
	1252202124	Bearing S2B (Short) OD +.010" / ID Std
	1252102127	Bearing S2A OD Std / ID +.010"
	1252212127	Bearing S2B (Long) OD Std / ID +.010"
	1252419161	Piston Ring S4 T/End(1"std) +0.010"
	1252139127	Bearing S3A Standard OD / -.010" ID
	1252102124	Bearing S2A OD +.010" / ID Std
	1252102120	Bearing S2A OD +.010" / ID -.010"
	1252201127	Bearing S1B OD Std / ID -.010"
	1252201124	Bearing S1B OD +.010" / ID Std"
	1252201120	Bearing S1B OD +.010" / ID -.010"
592	1100180610	Bolt (Comp end)
125638	1250404350	Shaft Nut 4MD
125647	1150400170	Piston Ring
125648	1250404250	Shim 0.003
125649	1250404251	Shim 0.005"
125650	1250404252	Shim 0.010"
127305	1250403140	Snap Ring
128565	1250404405	C/W 4MD-458 (N/A from SCH)
128936	1252103170	Piston Ring 3LM/S3A Comp End ssb 310279
129109	1100040180	Piston Ring T04B T/end
129119	1900000035	Gasket. Oil Inlet T12
129120	1900000025	Gasket. Oil Outlet T12
129533	1250404142	Snap Ring
129577	1152303170	Piston Ring
130087	1152302140	SNAP RING H2C / 3LKS
130282	1301036140	Snap Ring (H.S.K)
130665	1100120645	Nut. V Band clamp. T12 ssb 510927
132040	1900000003	GASKET
133125	1250404346	V Band Clamp Assy Comp/Hsg 9"
134058	1250404140	Snap Ring
135209	1150400160	Piston Ring (HCSKM)
135619	1250404100	Bearing 4B-D-V4HD-4MD Std OD/ Std ID With grooved ends & Grooved inside Dia ss 146740
135620	1250404260	Oil Control Sleeve 4B, 4MD, 4HD
135624	1250404402	Compressor Wheel 4MD-354
135625	1250404404	Compressor Wheel 4MD-454
135796	1250404200	Flinger Sleeve
135847	1250404340	Heat Shield
135947	1250404340	Heat Shield
135955	1250404240	Thrust Ring ssb 140963
135995	1250404240	Thrust Ring
136017	1250404409	C/W 4MD-754
136700	1250404345	V Band Clamp T/Hsg 7" 4MD
137008	1100120610	Bolt. (Insert Plate) T12
137016	1250404220	Spacer Sleeve
137017	1250404550	Lock tab, Thrust bearing 4MD
137281	1250404900	Noz Ring 4MD (.318)

137856	1250404310	Oil Deflector 4MD
137943	1250404320	Thrust Bearing 4MD (ssb 140964)
137945	1250404330	Spacer Plate
138178	1250404901	Noz Ring 4MD (.246)
138363	1250040100	Bearing (4LE- HC3 -HT3B -K361) Std OD/ Std ID
138991	1250404435	Shaft and Wheel 4MD ssb 181474
138992	1250404435	Shaft and Wheel 4MD ssb 181474
139051	1250404150	O Ring 4MD
139052	1250404141	Snap Ring 4HD
139053	1250404300	Insert Plate 4MD 4HD
139265	1250404155	O Ring C/End 4MD
139572	1301036220	Spacer Sleeve (4LE/K36)
140029	1250404260	Oil Control Sleeve 4B, 4MD, 4HD
140153	1250404346	V Band Clamp Assy Comp/Hsg 9"
140342	1250404346	V Band Clamp Assy Comp/Hsg 9"
140357	1250404346	V Band Clamp Assy Comp/Hsg 9"
140388	1250404435	Shaft & Wheel (ssb 181477)
140389	1250404435	Shaft & Wheel (ssb 181477)
140647	1250404405	C/W 4MD-458
140886	1250404411	C/W 4MD-755 also 4HD
140963	1250804240	Thrust Ring 4HD ss 135955
140964	1250404320	Thrust Bearing 4MD (ss137943) ssb186891
141062	1250404718	Core Assy. 4MD-754
141073	1250040350	Shaft nut (4LE/F/GK)
141073	1250040350	Shaft nut (4LE/F/GK)
141419	1250404450	B/Hsg Oil inlet and outlet without threaded mtg bosses on side
141525	1250403240	Thrust Ring 3LD
142066	1250403300	Insert Plate
142072	1250403451	Bearing Housing (Step Bore) ss 145181
142114	1150400172	Piston Ring ssb 310503
142228	1250040155	O Ring (4LE/F/GK) C/Hsg to B/Hsg
142229	1250040260	Oil Control Sleeve (4LE)
143000	1250030150	O Ring (Insert HSKM)
143137	1250404400	Compressor Wheel 4MD-351
143166	1250404408	C/W 4MD-659
143441	1250404716	Core Assy. 4MD-351
143442	1250404712	Core Assy 4MD-354
143444	1250404717	Core Assy 4MD-454 (ssb 310108)
143446	1250404718	Core Assy. 4MD-754
143823	1100120350	Shaft Nut
144077	1250403200	Flinger 3LD
144078	1250403310	Oil Deflector 3LD
144079	1250403320	Thrust Bearing 3LD
144080	1250403100	Bearing 3LD (Std)
144083	1250403435	Shaft / Wheel (1 groove) ssb 156689
144127	1250404406	C/W 4MD-558
144334	1301036240	THRUST RING
144538	1250504401	Comp Wheel 4LE 504 Radial
144834	1250403645	V Clamp
5220-109-0201	1200050630	Washer (2 Piece clamp Plate)
145181	1250403451	Bearing Housing (Step Bore) ssb 142072
146580	1250403450	Bearing Housing 3LD (step bore)
146594	1250403426	Comp Wheel 279 / 3LD
146595	1250403425	C/Wheel 259 / 3LD9
146599	1250403450	Bearing Housing 3LD (step bore)
146627	1250403561	Bolt
146643	1250403800	Comp Cover 259 / 3LD9 8 x M6-6H
146643	1250403801	Comp Cover 259 / 3LD9
146739	1250404320	Thrust Bearing 4MD
146740	1250404100	Bearing 4B-D-V4HD-4MD Std OD/ Std ID With grooved ends & Grooved inside Dia
146741	1100120610	Bolt. (Insert Plate) T12
146791	1100120610	Bolt. (Insert Plate) T12
146808	1150400160	Piston Ring (HCSKM) Stainless
147256	1250403701	Core Assy. 3LD-279
147427	1301027500	Clamp Plate (3LD/3LEP/K27 Comp.)
147571	1250403803	Comp Cover 259 / 3LD1 (8 x M6-6H)
147571	1250403802	Comp Cover 279 / 3LD1
147620	1250403425	C/Wheel 259 / 3LD9
147643	1100120350	Shaft Nut 3LD
147837	1900000037	Gasket (Oil Inlet) 3LM / S2A

148225	1250040120	Bearing 4L +0.010" OD/- .010"ID
148313	1301027500	Clamp Plate (3LD/3LEP/K27 Comp.)
148337	1150504200	Flinger Sleeve 4LE 2 ring groove (MELETTx 2 parts)
149403	1250403435	Shaft / Wheel (1 groove) ssb 156689
149925	1250040350	Shaft nut (4LE/F/GK)
151242	1250030150	O Ring (Insert HSKM)
152408	1301036240	THRUST RING
155434	1152302160	Piston Ring (H1C/H2C/3FD/J) Turb.End
156650	1250403645	V Clamp
156656	1250403435	Shaft / Wheel (1 groove)
156689	1250403435	Shaft / Wheel (1 groove) ss 144083 & 149403
156768	1250403645	V Clamp
158144	1250403321	Thrust Bearing 3LM
158185	1250040320	Thrust Bearing (4L-/HC3/3LKS)
158567	1250404550	Lock tab, Thrust bearing 4MD
158726	1150513300	Insert Plate 3FJ/3LM
158979	1250403450	Bearing Housing 3LD (step bore)
159608	1250040400	Comp Wheel 4LE 302 Radial
166084	1150704300	Insert Plate 4LGK/HC3
168084	1150704300	Insert Plate 4LGK/HC3
181253	1250040350	Shaft nut (4LE/F/GK)
181474	1250404435	Shaft and Wheel 4MD ss 138992
181477	1250404435	Shaft and Wheel 4MD (ss 140388 & 140389)
181478?	1250404435	Shaft and Wheel 4MD
181750	1150403750	Repair Kit 3LD
181751	1301504750	Service Kit 4LE/4LF
181847	1250404700	Core Assy 4MD-759
182004	1250404710	Core Assy 4MD-659
182005	1250404719	Core Assy 4MD-757
182006	1250404713	Core Assy 4MD-759
182042	1301027160	Piston Ring K26 Turb. & Comp.
182065	1150403450	Bearing Hsg. 3LD
182067	1250403701	Core Assy. 3LD-279
182185	1250404451	B/Hsg Oil inlet and outlet M8-6H
182196	1250404413	C/W 4MD759
182245	1250403700	Core Assy. 3LD-9 /3LD-259
182283	1250403861	Turbine Housing 3LD Twin Entry- 6 bolt discharge- 5/16 x18UNC 2.24sq in
182307	1152303435	Shaft & Wheel (HC3/K361) UNF T3
182353	1250504401	Comp Wheel 4LE 504 Radial
182421□312344	1301027600	Bolt (K27/T3 Turbine HT)
182561	1152303320	Thrust Bearing 4LEG (Ramped)
182562	1250040100	Bearing (4LE- HC3 -HT3B -K361) Std OD/ Std ID
182598	1250403860	Turbine Housing 6 holes M8-6H
182668	1100120350	Shaft Nut 3LD
182669	1250040350	Shaft nut (4LE/F/GK)
182670	1250404350	Shaft Nut 4MD (Nylock)
182674	1100120350	Shaft Nut 3LD
182764	1100120350	Shaft Nut
182891	1250403700	Core Assy. 3LD-9 /3LD-259
183189	1250404320	Thrust Bearing 4MD ssb 186891
183199	1250403425	C/Wheel 259 / 3LD9
183224	1250403753	Repair Kit 3LD/J
183466	1152303436	Shaft & Wheel (HC3 UNF T2)
183472	1150704300	Insert Plate 4LGK/HC3
183482	1250404550	Lock tab, Thrust bearing 4MD
183542	1150413100	Bearing 3FD/FJ ODStd/IDStd
183547	1301036220	Spacer Sleeve (4LE/K36)
185104	1200050435	Shaft & Wheel (T50) ssb 1200050436
185141	1150403435	Shaft & Wheel 3LD (2x Piston Ring Grooves)
185288	1250403100	Bearing 3LD (Std) Tin Plated
185319	1250030150	O RING
185727	1250040350	Shaft nut (4LE/F/GK)
185854	1250040127	Bearing 4L Std OD/- .010"ID
186135	1152302160	Piston Ring (H1C/H2C/3FD/J) Turb.End
186148	1250404100	Bearing 4B-D-V4HD-4MD Std OD/ Std ID With grooved ends & Grooved inside Dia ss 146740
186558	1250040320	Thrust Bearing (4L-/HC3/3LKS) ssb 182561
186648	1152303435	Shaft & Wheel (HC3/K361) UNF T3
186649	1152303436	Shaft & Wheel (HC3 UNF T2)
186654	1150403450	Bearing Hsg. 3LD Ford St/Bore use 1150403450 Sm/Bore
186774	1150403450	Bearing Hsg. 3LD UNC Smooth/Bore use

186790	1100040200	Thrust Collar (Dynamic TO4B)
186794	1100040100	Bearing (T3/TO4B) Standard
186796	1100040140	Snap Ring (thin)
186830	1100040320	THRUST BEARING
186835	1100040540	Lock Plate (TO4B Comp.)
186838	1100040500	Clamp Plate (TO4B Comp.)
186839	1100040480	CLAMP PLATE TURB
186840	1100040150	O Ring (B/Hsg TO4B)
186841	1100040160	Piston Ring TO4B (Step.Turb)
186842	1100040170	Piston Ring T04B C/E
186842	1252102170	Piston Ring S2A/S2B
186843	1250403561	Bolt
186847	1100040520	Lock Plate (TO4B Turb.)
186891	1250404320	Thrust Bearing 4MD ss 140964
188203	1200050100	Bearing (Cummins ST/ VT 50)
188379	1152303320	Thrust Bearing (4L-/HC3/3LKS) as 182561 but wiyh oil filter
188552	1200050750	Service Kit T-ST-VT 50 Cum Lrg
188553	1200050751	Service Kit T-ST-VT 50 Cum Sml
188554	1200050280	Heat Packing (Cummins ST/VT50)
188555	1200050281	Fiber Insert (Cummins ST/VT50)
188556	1200050156	O RING
188557	1200050150	O Ring (Seal Plate)Cum ST/VT50
188558	1200050155	O Ring (B/Hsg) Cummins ST/VT50
188559	1200050160	Piston Ring (Turb) CummST/VT50
188560	1200050170	Piston Ring (Comp) CummST/VT50
188562	1200050600	Bolt (2 piece Clamp) ST/VT50
188595	1200050450	Bearing Housing (T50-ST50-VT50)
188597	1200050300	Insert Seal Plate (S/Back) T50
188985	1252419100	Bearing S4 Range ss (199910 Brg +199909 Washer)
188990	1100180140	Snap Ring.
189003	1200050436	Shaft & Wheel (T50) ss 1200050435
189089	1250040350	Shaft nut (4LE/F/GK)
189906	1252139100	Bearing S3A Standard
191750	1152302170	Piston Ring (H1C-H2C) Comp End
191996	1100180350	Nut
192510	1100120350	Shaft Nut
192511	1250040350	Shaft nut (4LE/F/GK)
192512	1100040350	Shaft Nut (TO4B T3 RHT)
192871	1250404100	Bearing 4B-D-V4HD-4MD Std OD/ Std ID With grooved ends & Grooved inside Dia ss 146740
194118	1250404350	Shaft Nut 4MD
194118	1250404350	Shaft Nut 4MD (
194281	1252202150	O Ring (Insert)S2A/ S2B/S4D (Black)
194787	1252419124	Bearing S4A/D +.010" OD / Std OD
194789	1252419120	Bearing S4 +.010" OD / -.010" OD
194798	1252419160	Piston Ring T/E S4 (1" dia)
194914	1252102100	Bearing S2A Std. / Std.
194931	1252202100	Bearing S2B Std. / Std. Short)
196457	1252202150	O Ring (Insert) S2B (Orange) S2B/S4A
197087	1250204150	O Ring 4B
197651	1250403300	Insert Plate
199909	*	Washer (199909 Washer 199910 Brg) ssb 188985 Brg with no washer
199910	1252419100	Bearing S4 Std (199910 Brg +199909 Washer) ssb 188985 with no washer
310010	1100040360	Seal Plate T04B Dynamic
310063	1100040750	Service Kit TO4B
310096	1100040400	Comp.Wheel (TO4B)
310106	1250404712	Core Assy 4MD-354
310108	1250404717	Core Assy 4MD-454 ss 143444)
310139	1250404716	Core Assy. 4MD-351
310187	1100040350	Shaft Nut (TO4B T3 RHT)
310247	1100120645	Nut. V Band clamp. T12
310278	1152303170	PISTON RING .750"
310279	1252103170	Piston Ring 3LD/3LDA/3LM/S3A ss128936
310416	1200050170	Piston Ring (Comp) CummST/VT50
310503	1150400172	Piston Ring ss 142114
310503	1150400170	Piston Ring
310630	1401405160	Piston Ring T/E TC06
310631	1401405170	Piston Ring TDO5/TDO6 Comp end
310637	1301504750	Service Kit 4LE/4LF
310649	1401404150	O Ring (Seal Plate TD04)
310650	1401404155	O Ring (TD04 B/Hsg / Chsg)

310667	1252103170	Piston Ring 3LM Comp End
310724	1150400170	Piston Ring
310727	1150400170	Piston Ring
310858	1301027435	Shaft & Wheel (K27 F/Back C/W) RHTssb 5327-120-5013 LHT
310888	1250404752	Overhal Kit 4MD
310937	1301028150	O Ring K28
310938	1301027581	Washer (K27 Seal Plate)
310946	1301027101	Bearing (Grooved O.D. K27)
310947	1301027310	Oil Deflector (K26/K27)
310979	1301027610	Bolt (K27/K33/H2C/Garrett S/P to C/Hsg)
310982	1301027350	Shaft Nut (K24/26/27) M6x6 SW12 (5326-128-0201)
310996	1301026620	Cap screws K26/27/ S/P to B/Hsg
311038	1301027320	Thrust Bearing (K27)
311084	1251704435	Shaft & Wheel 4LGK (83.65)
311413	1301027320	Thrust Bearing (K27)
311496	1900000027	Gasket Oil Outlet T04B
311708	1100040360	Seal Plate T04B Dynamic
311718	1301027360	Seal Plate (K27)
311721	1301027340	Turbine Back Plate (K27) (Cast)5327-165-2000
311725	1301027200	Thrust Spacer/Flinger (K26/27)
311740	1100180100	Bearing OD. Std / ID Std. T12 / T18
311741	1301027220	Spacer sleeve (K26/K27)
311742	1301027240	Thrust Ring (K26/K27)
311754	1301027150	O Ring (K27 Comp. Hsg.)
311807	1301027400	Comp Wheel K27 B/Curved 3060G
311808	1301027403	Comp Wheel K27 B/Curved 3064G
311809	1301027402	Comp.Wheel K27 Radial 2963U (Radial)
311810	1301027406	Comp. Wheel K27 B/Curved 2970N
311836	1301027701	Core Assy K27-3060G
311837	1301027702	Core Assy K27-3064G
311839	1301027450	Bearing Housing (K27 L/Turb)
311876	1101461550	Lock Plate TV series
311882	1100045160	Piston Ring Step Bore(T12/45/51/TV)
311883	1100045170	Piston Ring TA45/ TA51/T18 /T 12 /T 6 C/E
311885	1100180320	Thrust Washer T12
311888	1101061200	Thrust Collar (TV61-81 T18A)ssb1101061200
311889	1100180220	THRUST SPACER T18A/TV71-81
311899	1100180190	Wear Washer (Bearing) T12 / T18
311901	1100120350	Shaft Nut
311902	1100180350	Nut
311903	1101680620	BOLT
312292	1301027151	O Ring
312304	1301027100	Bearing (Smooth O.D. K27)
312325	1101280750	Repair Kit TV6/7/8
312340	1152303435	Shaft & Wheel (HC3/K361) UNF T3
312342	1301027405	Comp. Wheel K27 Radial 2966V
312344□312344	1301027600	Bolt (K27/T3 Turbine HT)
312455	1252212100	Bearing S2B Std. / Std. (Long)
312553	1252219155	O Ring (C/Hsg) S1A/S1B/S1BG
312697	1301014160	Piston Ring (K14 - K27)
312758	1252201100	Bearing Std. / Std. S1B
312836	1301027455	Bearing Housing (K27 S/Turb)
312837	1301027342	Turbine Back Plate (K27) Stain/Steel Pressing (Medium dia)□edium)
312855	1301027438	Shaft & Wheel K27 RHT
312856	1301027436	Shaft & Wheel K27 (S/Back C/W) RHT
312861	1301027341	Heat Shield (Pressing)
312957	1301027480	Clamp Plate (K27/3LKZ Turb)
313119	1301027455	Bearing Housing (K27 S/Turb)
313231	1301027711	Core Assy K27-3060G StH/Shield
313454	1301027724	Core Assy K27 (3262)
313627	1301027320	Thrust Bearing (K27)
313713	1301027425	Comp. Wheel K27Bcur Sbk3262MGB
510927	1100120645	Nut. V Band clamp. T12 ss 130665